


EN User Manual Tumble Dryer

USER MANUAL





CONTENTS

1. SAFETY INFORMATION	3
2. SAFETY INSTRUCTIONS	6
3. PRODUCT DESCRIPTION	
4. CONTROL PANEL	9
5. PROGRAMME	
6. OPTIONS	12
7. BEFORE FIRST USE	13
8. DAILY USE	15
9. HINTS AND TIPS	17
10. CARE AND CLEANING	
11. TROUBLESHOOTING	21
12. TECHNICAL DATA	24
13. ACCESSORIES	
14. PRODUCT INFORMATION SHEET IN REFERENCE TO E.U. REGU	JLATION
1369/2017	

FOR PERFECT RESULTS

Thank you for choosing this AEG product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler – features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it. Visit our website to:



Get usage advice, brochures, trouble shooter, service and repair information: www.aeg.com/support

Register your product for better service: www.registeraeg.com

Buy Accessories, Consumables and Original spare parts for your appliance: www.aeg.com/shop

CUSTOMER CARE AND SERVICE

Always use original spare parts.

When contacting our Authorised Service Centre, ensure that you have the following data available: Model, PNC, Serial Number.

The information can be found on the rating plate.

- A Warning / Caution-Safety information
- (i) General information and tips
- Environmental information

Subject to change without notice.

1. A SAFETY INFORMATION

Before beginning the installation and use of this appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

- Read the supplied instructions.

Warning: Risk of fire / Flammable materials. The appliance contains flammable gas, propane (R290), a gas with a high level of environmental compatibility. Keep fire and ignition sources away from the appliance. Be careful not to cause damage to the refrigerant circuit containing propane.

1.1 Children and vulnerable people safety



WARNING!

Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children between 3 and 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised.
- Children of less than 3 years of age should be kept away from the appliance unless continuously supervised.
- Do not let children play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.

- · Keep detergents away from children.
- Keep children and pets away from the appliance when the door is open.
- If the appliance has a child safety device, it should be activated.
- Children shall not carry out cleaning and user
 maintenance of the appliance without supervision.

1.2 General Safety

- Do not change the specification of this appliance.
- If the tumble dryer is put on top of a washing machine, use the stacking kit. The stacking kit, available from your authorized vendor, can be used only with the appliance specified in the instructions supplied with the accessory. Read it carefully before installation (refer to the Installation leaflet).
- The appliance can be installed as freestanding or below a kitchen counter with correct space (refer to the Installation leaflet).
- Do not install the appliance behind a lockable door, a sliding door or a door with a hinge on the opposite side, that would prevent the appliance door from being fully open.
- The ventilation opening in the base must not be covered by a carpet, mat, or any floor covering.
- CAUTION: The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- Connect the mains plug to the mains socket only at the end of the installation process. Make sure that the mains plug is accessible after installation.
- Ensure good air ventilation in the room where the appliance is installed to avoid the backflow of unwanted gases into the room from appliances burning gas or other fuels, including open fires.
- WARNING: Do not install the appliance in an environment with no air exchange.

The appliance contains flammable gas, propane (R290), a gas with a high level of environmental compatibility. Keep fire and ignition sources away from the appliance. Be careful not to cause damage to the refrigerant circuit containing propane.

- WARNING: In the appliance enclosure or in the built in structure, keep ventilation opening clear of obstruction.
- WARNING: Do not damage the refrigerant circuit.
- If the mains power supply cable is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- Do not exceed the maximum load of 8,0 kg (refer to the "Programme chart" chapter).
- Do not use the appliance if items have been soiled with industrial chemicals.
- Wipe away lint or packaging debris that has accumulated around the appliance.
- Do not run the appliance without a filter. Clean the lint filter before or after each use.
- Do not dry unwashed items in the tumble dryer.
- Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.
- Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be dried in the tumble dryer.
- Fabric softeners, or similar products, should only be used as specified by the product manufacturer's instructions.
- Remove all objects from items that could be a source of fire ignition such as lighters or matches.

- WARNING: Never stop a tumble dryer before the end of the drying cycle unless all items are quickly removed and spread out so that the heat is dissipated.
- Before any maintenance operation, deactivate the appliance and disconnect the mains plug from the socket.

2. SAFETY INSTRUCTIONS

2.1 Installation

Warning: Risk of fire / Flammable materials.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Follow the installation instructions supplied with the appliance.
- Do not install the appliance in an environment with no air exchange The appliance contains flammable gas, propane (R290), a gas with a high level of environmental compatibility. Keep fire and ignition sources away from the appliance. Be careful not to cause damage to the refrigerant circuit containing propane.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not install or use the appliance where the temperature can be lower than 5°C or higher than 35°C.
- The floor area on which the appliance is to be installed must be flat, stable, heat resistant and clean.
- Make sure that there is air circulation between the appliance and the floor.
- Always keep the appliance vertical when it is being moved.
- The rear surface of the appliance must be put against a wall.
- When the appliance is in its permanent position, check if it is levelled correctly with the aid of a spirit level. If it is not, adjust the feet accordingly.

2.2 Electrical connection

WARNING!

Â

Risk of fire and electric shock.

- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Do not touch the mains cable or the mains plug with wet hands.

2.3 Use

WAI Risk

WARNING! Risk of injury

Risk of injury, electric shock, fire, burns or damage to the appliance.

Warning: Risk of fire / Flammable materials. The appliance contains flammable gas, propane (R290), a gas with a high level of environmental compatibility. Keep fire and ignition sources away from the appliance. Be careful not to cause damage to the refrigerant circuit containing propane.

- This appliance is for household use only.
- Do not dry damaged (torn, frayed) items that contain padding or fillings.
- If laundry has been washed with a stain remover, carry out an additional rinse cycle before starting a drying cycle.
- Dry only fabrics that are suitable to dry in the appliance. Follow the cleaning instruction on the item label.
- Do not drink or prepare food with the condensed water/distilled water. It can cause health problems to people and pets.
- Do not sit or stand on the open door of the appliance.
- Do not dry dripping wet clothes in the appliance.

2.4 Internal lighting



WARNING!

∆ Risk of injury.

- Concerning the lamp(s) inside this product and spare part lamps sold separately: These lamps are intended to withstand extreme physical conditions in household appliances, such as temperature, vibration, humidity, or are intended to signal information about the operational status of the appliance. They are not intended to be used in other applications and are not suitable for household room illumination.
- To replace the internal lighting, contact the Authorised Service Centre.

2.5 Care and cleaning

WARNING!



Risk of injury or damage to the appliance.

Warning: Risk of fire / Flammable materials. The appliance contains flammable gas, propane (R290), a gas with a high level of environmental compatibility. Keep fire and ignition sources away from the appliance. Be careful not to cause damage to the refrigerant circuit containing propane.

- Do not use water spray and steam to clean the appliance.
- Clean the appliance with a moist soft cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- Be careful when you clean the appliance to prevent damage to the cooling system.

2.6 Compressor



WARNING!

Risk of damage to the appliance.

 The compressor and its system in the tumble dryer is filled with a special agent which is free from fluoro-chlorohydrocarbons. This system must stay tight. The damage of the system can cause a leakage.

2.7 Service

- To repair the appliance contact the Authorised Service Centre.
- Use original spare parts only.

2.8 Disposal

WARNING!




Risk of injury or suffocation.

Warning: Risk of fire / Risk of material damage and damage to the appliance.

- Disconnect the appliance from the mains electrical and water supplies.
- Cut off the mains electrical cable close to the appliance and dispose of it.
- The appliance contains flammable gas (R290). Contact your municipal authority for information on how to discard the appliance correctly.
- Remove the door catch to prevent children or pets from becoming trapped in the drum.
- Dispose of the appliance in accordance with local requirements for the disposal of Waste Electrical and Electronic Equipment (WEEE).

3. PRODUCT DESCRIPTION




- 1 Water container
- 2 Control panel
- 3 Appliance door
- 4 Filter
- 5 Rating plate

- 6 Airflow slots7 Condenser lid8 Condenser cover
- 9 Adjustable feet


i

For ease of loading laundry or ease of installation the door is reversible. (see separate leaflet).

4. CONTROL PANEL



4.1 Display



Symbol on the display	Symbol description
	laundry maximum load
Ċ	delay start option on
30'-20h	delay start selection (30min-20h)
1:50	cycle time indication
Ø€	buzzer off

Symbol on the display	Symbol description
•	child lock on
⊿, ⊞, ⊞⁺, ☀	laundry dryness: iron dry, cupboard dry, cupboard dry +, extra dry
Er.	indicator: drain the water container
۲	indicator: <i>clean the filter</i>
≣	indicator: check the condenser
⊖ [™]	time dry option on
101-5:00	time programme selection (10min-2h)
555	indicator: <i>drying phase</i>
Ũ	indicator: crease guard phase
Å	indicator: <i>cooling phase</i>

5. PROGRAMME

Programme	Load ¹⁾	Properties / Fabric mark	
2) Cottons Eco	8,0 kg	Cycle to be used to dry cotton with "cotton cupboard" dryness level, with maximum energy saving.	/ 🖸 🖸
Cottons	8,0 kg	Cycle defined to dry cottons items of different size / different weaving altogether.	/ 🖸 🖸
Synthetics	3,5 kg	Synthetic and mixed fabrics.	
Mixed	3 kg	Cotton and synthetic fabrics.	
Wool	1 kg	Woollen fabrics. Gentle drying of washable wool lens. Remove items immediately when the pro- gramme is completed.	
Silk	1 kg	Silk suitable for tumble drying.	000

Programme	Load ¹⁾	Properties / Fabric mark	
Easy Iron	1 kg (or 5 shirts)	Easy care fabrics for which a minimum of ironing is necessary. The drying results can be different from one type of fabric to another. Shake the items before putting them in the appliance. When the programme has ended, immediately remove the items and put them on a hanger.	
Bed Linen	3 kg	Bed linen such as single and double sheets, pillowcases, duvet cov- / 🖸 🖸 🔘 er.	
Duvet	3 kg	Single or double duvets and pillows (with feather, down or synthetic fillings).	
Sport	2 kg	Sportswear, thin and light fabrics, microfiber, polyester.	

1) The maximum weight refers to dry items.

2) The Cottons Eco programme is the "Standard cotton programme" according to Commission Regulation EU No. 392/2012. It is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for drying wet cotton laundry.

5.1 Programmes and options selection

		Optio	ons	
Programmes ¹⁾	Dryness Level	Anti-crease	Refresh	Time Drying
Cottons Eco	<u>(</u>)2)			
Cottons		•		•
Synthetics	<u> </u>			•
Mixed	<u>(</u>)2)		-	
Wool	<u>(</u> 2)			■ 3)
Silk	<u>(</u> 2)	-		
Easy Iron	2)	-		
Bed Linen	<u>(</u>)2)			
Duvet	<u>(;</u> 2)			

	Options			
Programmes ¹⁾	Dryness Level	Anti-crease	Refresh	Time Drying
Sport	<u>.</u> 2)			

1) Together with the programme you can set 1 or more options.

2) Set by default

3) See chapter OPTIONS: Time Drying on Wool programme

5.2 Consumption data

Program	Spun at / residual humidity	Drying time ¹⁾	Energy consump- tion ²⁾
	Cottons Eco 8,0 kg		
D cupboard dry	1400 rpm / 50%	145 min	1,59 kWh
	1000 rpm / 60%	178 min	1,93 kWh
	Cottons 8,0 kg		
a iron dry	1400 rpm / 50%	110 min	1,18 kWh
	1000 rpm / 60%	140 min	1,45 kWh
Cottons Eco 4,0 kg			
Cupboard dry	1400 rpm / 50%	89 min	0,90 kWh
	1000 rpm / 60%	104 min	1,08 kWh
	Synthetics 3,5 kg		
Cupboard dry	1200 rpm / 40%	62 min	0,59 kWh
	800 rpm / 50%	81 min	0,79 kWh

1) For partial loads, the cycle time is shorter and appliance uses less energy.

 $^{\rm (2)}$ Improper ambient temperature and/or poorly centrifuged laundry can prolong cycle time and increase the energy consumption.

6. OPTIONS

6.1 Dryness Level

This option helps to achieve requested laundry dryness. Possible selections:

 $a = \pm$ - ready to iron - **iron dry** level.

 $\square = = - ready to store -$ **cupboard dry**level - default selection which is related to the programme.

 $_ = = - ready to store - cupboard dry + level.$

6.2 Anti-crease

Extends up to 120 minutes the anticrease phase (30 minutes) at the end of the drying cycle. After drying phase drum rotates from time to time to prevent creases. Laundry can be removed during the anti-crease phase.

6.3 Refresh

To refresh clothes that were in storage. Maximal load cannot exceed 1 kg.

6.4 Time Drying

For cottons, synthetics and mixed. Lets the user to set drying time from minimum 10 min to maximum of 2 hours (in 10 min steps). When this option is maximum, load indicator disappears.

i

The cycle lasts as long as set drying time regardless of the size of a load and its dryness.

TIME DRYING RECOMMENDATION

10 - 20 action of cool air only (no heatmin er).

20 - 40 min additional drying to improve dryness after previous drying cycle.

7. BEFORE FIRST USE



Rear drum locks are removed automatically when dryer is activated for the first time. Possible to hear some noise.

TIME DRYING RECOMMENDATION

> 40 min full drying of the small laundry loads up to 4 kg, well spun (>1200 rpm).

6.5 Time Drying on Wool program

Option applicable to Wool program to adjust final dryness level to more dry or less dry.

6.6 Delay Start

- Lets to delay the start of a drying program from minimum of 30 minutes to maximum of 20 hours.
- 1. Set the drying program and options.
- 2. Touch Delay Start button again and again.

Time of delay is on the display (e.g.

2h if the program has to start after 12 hours.)

3. To activate Delay Start option, touch the Start/Pause button.

Time to start decreases on the display.

6.7 Buzzer └─ ⊯ ──

The sound is heard at the:

- cycle end
- start and end of crease guard phase The buzzer option is by default always on. You can use this option to activate or deactivate the sound.
 - **1** It is highly recommended to start any programme for the first time without the load for a few seconds to ensure that the rear drum locks are removed properly.


To unlock the rear drum locks:


- 1. Switch on the appliance.
- 2. Set any programme.
- 3. Press the Start/Pause button.


Drum starts to rotate. Rear drum locks are automatically deactivated.

 (\mathbf{i})

If the drum still does not rotate, please release the rear drum locks manually (to do that, please use provided key).







Before you use the appliance to dry items:

- Clean the tumble dryer drum with a moist cloth.
- Start a 1 hour programme with moist laundry.
 - **i** At the beginning of the drying cycle (first 3-5 min) there could be a slightly higher sound level. This is due to the compressor starting up. This is normal for compressor powered appliances such as refrigerators and freezers.

7.1 Unusual smell

The appliance is tightly packed.

After product unpacking you can feel an unusual smell. This is normal for brand new products.


Appliance is built of several different types of material which all together can generate unusual smell.

Over usage time, after few drying cycles unusual smell gradually disappears.


7.2 Noises

Different noises may be heard at different times during the drying cycle. They are perfectly normal operating sounds.


Working compressor.




Rotating drum.



Working fans.



Working pump and transferring condensation to the tank.



8. DAILY USE

8.1 Preparing the laundry

Ø

Very often the clothes after washing cycle are kneaded and tangled altogether. Drying kneaded and tangled clothes is inefficient. To assure proper air flow and even drying it is recommended to shake and load one by one the clothes to the tumble dryer.

To assure proper drying process:

- · Close the zips.
- Close the fasteners of duvet covers.
- Do not dry ties or ribbons loose (e.g. apron ribbons). Tie them before you start a programme.
- Remove all items from pockets.
- Turn items with the internal layer made of cotton inside out. Cotton layer must be faced outwards.

- Always set the programme suitable for the type of laundry.
- Do not put light and dark colours together.
- Use suitable programme for cottons, jersey and knitwear to reduce shrinkage.
- Do not exceed the maximum load stated in the programmes chapter or shown on the display.
- Dry only the laundry that is suitable for tumble drying. Refer to the fabric label on the items.
- Do not dry large and small items together. Small items can be trapped inside the large items and remain wet.
- Shake the large clothes, fabrics before placing in the tumble dryer. It is to avoid moist places inside the fabric after the drying cycle.


Fabric label	Description
Ø	Laundry is suitable for tumble drying.
$\overline{\mathbf{O}}$	Laundry is suitable for tumble drying at higher temperatures.
\odot	Laundry is suitable for tumble drying at low temperatures only.
	Laundry is not suitable for tumble drying.

8.2 Loading the laundry




CAUTION!

Ensure the laundry is not trapped between the appliance door and the rubber seal.



- 1. Pull open the appliance door.
- 2. Load the laundry one item at a time.
- 3. Close the appliance door.

8.3 Turning on the appliance



To turn on the appliance:

Push the On/Off button.

If the appliance is on, some indicators appear on the display.

8.4 Auto Off function


To decrease the energy consumption, the Auto Off function turns the appliance off automatically:

- if the Start/Pause touch button is not touched within 5 minutes.
- 5 minutes after a cycle ends.

Push the On/Off button to turn on the appliance.

If the appliance is on, some indications appear on the display.

8.5 Setting a programme



Use the programme dial to set the programme.


The approximate programme duration appears on the display.



Real drying time will depend on type of the load (quantity and composition), the room temperature and the humidity of your laundry after spin drying phase.

8.6 Options

Together with the programme you can set 1 or more special options.



To activate or deactivate an option touch the relevant button or a two button combination.

its symbol appears on the display or the led above the corresponding button lights up.


8.7 Child lock option

The child lock can be set to prevent children from playing with the appliance. The child lock option locks all touch buttons and the program dial (this option does not lock the **On/Off** button).

You can activate the child lock option:

- before you touch the Start/Pause button - the appliance cannot start
- after you touch the Start/Pause button - programs and option selection is unavailable.

Child lock option activation:




- 1. Turn the dryer on.
- 2. Select 1 of the available programs.
- 3. Touch and hold down 2 buttons at the same time.

The symbol 🖬 appears on the display.

4. To deactivate the child lock, touch the above buttons again until the symbol disappears.

8.8 Starting a program



To start the program:

Touch the **Start/Pause** button. The appliance starts and the LED above the button stops flashing and stays on.

9. HINTS AND TIPS

9.1 Ecological hints

- Spin the laundry well before drying.
- Do not exceed the load sizes which are specified in the programmes chapter.

8.9 Program change

To change a program:

- 1. Push the On/Off button to turn the appliance off.
- 2. Push the On/Off button again to turn on the appliance.
- 3. Set a new program.

8.10 Programme end

(1) Clean the filter and drain the water container after each drying cycle. (See chapter CARE AND CLEANING.)

If the drying cycle is finished, the symbol

appears on the display. If the Buzzer option is activated, the acoustic signal sounds intermittently for 1 minute.



If you do not turn off the appliance, the anti-crease phase starts (not active with all programmes). Flashing

symbol signals the execution of the anti-crease phase. Laundry can be removed during this phase.

To remove the laundry:

- 1. Push the On/Off button for 2 seconds to turn the appliance off.
- 2. Open the appliance door.
- 3. Remove the laundry.
- 4. Close the appliance door.

Possible causes of unsatisfactory drying results:

- Inadequate default dryness level settings. See chapter Adjustment of default dryness level
- Room temperature is too low or too high. Optimal room temperature is between 18°-25°C.
- Clean the filter after each drying cycle.
- Do not use fabric softener to wash and then dry. In the tumble dryer laundry becomes soft automatically.
- The water from the water container can be used to iron the clothes. You

must first filter the water to eliminate remaining textile fibres (simple coffee filter is suitable).

- Always keep the airflow slots at the bottom of the appliance clear.
- Make sure there is good airflow where the appliance is to be installed.

9.2 Adjustment of default dryness level

To change the default dryness level:

- 1. Turn the appliance on.
- 2. Wait approximately 8 seconds.
- 3. Select 1 of the available programmes.
- 4. Touch and hold down the **Dryness** Level and **Refresh** buttons at the same time.

One of the symbols appears on the display:

- [] Maximum dryness
- **CO**₂ Extra dryness
- EDE Standard dryness
- Touch the Start/Pause button repeatedly until you reach the desired dryness level.

Dryness level	Display symbol		
Maximum dryness	‡ <u>\</u>	٢٥_	
Extra dry- ness	+ []]]	CO=	

10. CARE AND CLEANING

10.1 Cleaning the filter

At the end of each cycle the *Filter* symbol comes on the display and you must clean the filter.

i

The filter collects the lint during the drying cycle.

Dryness level		Display symbol
Standard dryness	555	E 0 3

 To memorise the setting touch and hold down the Dryness Level and Refresh buttons at the same time for approximately 2 seconds.

9.3 Deactivating the tank indicator $\widehat{\Leftrightarrow}_{A}$

The water container indicator is activated by default. It illuminates at the end of the drying cycle or during the cycle if the water reservoir is full. If the draining kit is installed the water container is drained automatically and the indicator can be deactivated.

To deactivate the indicator:

- 1. Turn the appliance on.
- 2. Wait approximately 8 seconds.
- 3. Select 1 of the available programmes.
- Touch and hold down Refresh and Time Drying buttons at the same time.

One of 2 configurations is possible:


- the Tank indicator: ^{Con} is on if the symbol ___ l appears - the water container indicator is permanently activated
- the Tank indicator: is off if the symbol ___ appears - the water container indicator is permanently deactivated
- **1** To achieve the best drying performances clean the filter regularly, clogged filter lead to longer cycles and energy consumption increase. Use your hand to clean the filter, and if necessary, a vacuum cleaner.




CAUTION!

Avoid the use of water to clean the filter. Instead throw away lint in the dustbin (avoid dispersion of plastic fiber in water ambient).

1. Open the door. Pull the filter up.



2. Push the hook to open the filter.




3. Gather lint with hand from both internal parts of the filter.



Throw the lint in the dustbin.

- 4. If necessary, clean the filter with a vacuum cleaner. Close the filter.
- If necessary, remove lint from the filter socket and gasket. You can use a vacuum cleaner. Place the filter back inside the filter socket.



10.2 Emptying the water container

Empty the condensed water container after each drying cycle.

If the condensed water container is full, the programme stops automatically. The


Tank symbol comes on the display and you must empty the water container.

To empty the water container:

1. Pull the water container out keeping it in a horizontal position.



 Pull the plastic connection out and drain the water into a basin or equivalent receptacle.



- 3. Push the plastic connection back in and place the water container back into position.
- 4. To continue the programme press the Start/Pause button.


10.3 Cleaning the condenser

If the symbol \Rightarrow *Condenser* flashes on the display, inspect the condenser and its compartment. If it is dirty, clean it. Do the check not less than once a 6 months.


WARNING! Do not touch the metal surface with bare hands. Risk of injury. Wear protective gloves. Clean carefully to avoid damaging the metal surface.

To inspect:

1. Open the door. Pull the filter up.




2. Open the condenser cover.




3. Turn the lever to unlock the condenser lid.



4. Lower the condenser lid.



 If necessary, remove the fluff from the condenser and its compartment. You can use a wet cloth and/or a vacuum cleaner with a brush attachment.



- 6. Close the condenser lid.
- 7. Turn the lever until it clicks into position.
- 8. Put the filter back.

10.4 Cleaning the humidity sensor

CAUTION!

Risk of humidity sensor damage. Do not use abrasive materials or steel wool to clean the sensor.

To assure best drying results the appliance is equipped with metal humidity sensor. It is placed on the inner side of the door area.


Over usage time the surface of the sensor may get dirty what deteriorates the drying performance.

We recommend to clean the sensor at least 3 or 4 times or if you observe the drop of drying performance.

To clean you can use harder side of dish-washing sponge and bit of vinegar or dish soap.

To clean the sensor:

- 1. Open the loading door.
- 2. Clean the surfaces of the humidity sensor wiping off the metal surface several times.



10.5 Cleaning the drum

WARNING!

Disconnect the appliance before you clean it.

Use a standard neutral soap detergent to clean the inner surface of the drum and

11. TROUBLESHOOTING



WARNING!

Refer to Safety chapters.

11.1 Error Codes

The appliance does not start or it stops during operation.

First try to find a solution to the problem (refer to the table). If the problem persists, contact the Authorised Service Centre.



WARNING!

Deactivate the appliance before carrying out any check.

In case of major problems, the acoustic signals operate, the display shows an alarm code and the Start/Pause button may flash continuously:

Possible cause	Possible cause	Remedy
E5A	Appliance Motor overloaded. Too much laundry or entrap in the drum.	The programme was not comple- ted. Remove the laundry from the drum, set the programme and re- start the cycle.

drum lifters. Dry the cleaned surfaces with a soft cloth.



CAUTION!

Do not use abrasive materials or steel wool to clean the drum.

10.6 Cleaning the control panel and housing

Use a standard neutral soap detergent to clean the control panel and housing.

Use a moist cloth to clean. Dry the cleaned surfaces with a soft cloth.



CAUTION!

Do not use furniture cleaning agents or cleaning agents which can cause corrosion.

10.7 Cleaning the airflow slots

Use a vacuum cleaner to remove fluff from the airflow slots.

Possible cause	Possible cause	Remedy
E97	Internal fail. No communication be- tween electronic elements of the appliance.	The programme was not finished properly or the appliance stoped too early. Switch the appliance off and on again. If the alarm code appears again, contact the Authorised Service Centre.
EH0	The mains supply is unstable.	When the appliance is showing EH0 , please wait until main supply is stable than press start. If the ap- pliance pause the cycle without any indication then press the cycle start. If the warning will occur check the power cord / socket in- tegrity or main supply.

If the display shows other alarm codes, deactivate and activate the appliance. If the problem continues, contact the Authorised Service Centre.

In case of different problem with the Tumble dryer check the table below for possible solutions.

11.2 Troubleshooting

Problem	Possible cause	Remedy
	The tumble dryer is not connected to the mains supply.	Connect it to the mains socket. Check the fuse in the fuse box (do- mestic installation).
The tumble dry-	The door is open.	Close the door.
er does not op- erate.	The On/Off button was not pushed.	Push the On/Off button.
	The Start/Pause button was not touched.	Touch the Start/Pause button.
	The appliance is in standby mode.	Push the On/Off button.

Problem	Possible cause	Remedy
	Incorrect programme selection.	Select a suitable programme. ¹⁾
	The filter is clogged.	Clean the filter. ²⁾
	Dryness Level option was set to <i>iron dry</i> . ³⁾	Change Dryness Level option to a higher level.
Unsatisfactory	The load was too large.	Do not exceed the maximum load size.
drying result.	The airflow slots are clogged.	Clean the airflow slots at the bot- tom of the appliance.
	There is some dirt on the humidity sensor in the drum.	Clean the front surface of the drum.
	The dryness level was not set to the desired level.	Adjust the dryness level. ⁴⁾
	The condenser is clogged.	Clean the condenser. 2)
The loading door does not	The filter is not locked into posi- tion.	Put the filter in the correct position.
close	Laundry is trapped between the door and the seal.	Remove trapped items and close the door.
It is not possible to change the programme or option.	After a cycle starts it is not possible to change the programme or option.	Turn the tumble dryer off and on. Change the programme or option as required.
It is not possible to select an op- tion. An acoustic signal is emit- ted.	The option you tried to select is not available for the selected pro- gramme.	Turn the tumble dryer off and on. Change the programme or option as required.
Unexpected du- ration time ap- pears on the display.	The drying duration is calculated according to load size and dampness.	This is automated - the appliance is working correctly.
A programme is inactive.	The water container is full.	Drain the water container, push the Start/Pause button. ²⁾

Problem	Possible cause	Remedy
The drying cycle is too short.	The load size is small.	Select a time programme. The time value must be related to the load. To dry one item or a small amount of laundry we recommend short drying times.
	The laundry is too dry.	Select an appropriate time pro- gramme or a higher dryness level (e.g. * <i>extra dry</i>)
Drying cycle too long ⁵⁾	The filter is clogged.	Clean the filter.
	The load is too large.	Do not exceed the maximum load size.
	The laundry was not spun sufficiently.	Spin the laundry well in the wash- ing machine.
	Too low or too high room tempera- ture - this is not the appliance mal- function.	Ensure a room temperature higher than $+5^{\circ}$ C and lower than $+35^{\circ}$ C. Optimal room temperature to ach- ieve best drying results is between $18^{\circ}-25^{\circ}$ C.

1) Follow the programme description — see the PROGRAMMES chapter .

2) See the CARE AND CLEANING chapter.

3) Only dryers with the Dryness Level option.

4) See the HINTS AND TIPS chapter .

⁵⁾ Note: After a maximum of 5 hours the drying cycle ends automatically.

11.3 Possible causes of unsatisfactory drying results:

- The filter is clogged. Clogged filter makes drying inefficient.
- The airflow slots are clogged.
- The humidity sensor is dirty.
- The drum is dirty.

Inadequate default dryness level settings. See chapter Adjustment of default dryness level

 Room temperature is too low or too high. Optimal room temperature is between 18°-25°C.

Height x Width x Depth	850 x 596 x 638 mm (maximal 663 mm)
Max. depth with the appliance door open	1108 mm
Max. width with the appliance door open	958 mm
Adjustable height	850 mm (+ 15 mm - feet regulation)
Drum volume	118
Maximum load volume	8,0 kg

Voltage	230 V
Frequency	50 Hz
Sound power level	66 dB
Total power	800 W
Energy efficiency class	A++
Energy consumption on the standard cotton programme with the full load. ¹⁾	1,93 kWh
Energy consumption on the standard cotton programme with the partial load. ²⁾	1,08 kWh
Annual energy consumption ³⁾	234,7 kWh
Left-on mode power absorption ⁴⁾	0,50 W
Off mode power absorption ⁴⁾	0,50 W
Type of use	Household
Allowed ambient temperature	+ 5°C to + 35°C
Level of protection against ingress of solid particles and moisture ensured by the pro- tective cover, except where the low voltage equipment has no protection against mois- ture	IPX4
Gas designation	R290
Weight	0,140 kg

¹⁾ With reference to EN 61121. 8,0 kg of cotton centrifuged at 1000 rpm.

2) With reference to EN 61121. 4,0 kg of cotton centrifuged at 1000 rpm.


³⁾ Energy consumption per year in kWh, based on 160 drying cycles of the standard cotton programme at full and partial load, and the consumption of the low-power modes. Actual energy consumption per cycle will depend on how the appliance is used (REGULATION (EU) No. 392/2012).

4) With reference to EN 61121.

The information given in the chart above is compliant with the EU Commission regulation 392/2012 implementing directive 2009/125/EC.

13. ACCESSORIES

13.1 Stacking kit




Accessory name: SKP11GW, STA9GW

Available from your authorised vendor.

Stacking kit can be used only between washing machines and tumble dryers specified in the leaflet. See the leaflet attached.

Read carefully the instructions supplied with the accessory.

13.2 Draining kit



Accessory name: DK11.

Available from your authorised vendor (can be attached to some types of tumble dryer)

For thorough draining of the condensed water into a basin, siphon, gully, etc. After installation, the water container is drained automatically. The water container must stay in the appliance.

The installed hose must be minimum 50 cm to maximum 100 cm from floor level. The hose cannot be in a loop. Decrease the length of the hose if necessary.

Read carefully the instructions supplied with the accessory.

14. PRODUCT INFORMATION SHEET IN REFERENCE TO E.U. REGULATION 1369/2017

Product Information Sheet

Trade Mark

Model	T7DBL831G PNC916098989
Rated capacity in kg	8,0
Air vented or condenser tumble dryer	Condenser
Energy efficiency class	A++
Energy consumption in kWh per year, based on 160 drying cy- cles of the standard cotton programme at full and partial load, and the consumption of the low-power modes. Actual energy consumption per cycle will depend on how the appliance is used.	234,7
Automatic tumble drier or non-automatic tumble drier	Automatic
Energy consumption of the standard cotton programme at full load in kWh	1,93
Energy consumption of the standard cotton programme at par- tial load in kWh	1,08
Power consumption of the off-mode in W	0,50
Power consumption in left-on mode in W	0,50
Duration of the left on mode in minutes	10
The 'standard cotton programme' used at full and partial load is the standard drying programme to which the information in the label and the fiche relates, this programme is suitable for drying normal wet cotton laundry and it is the most efficient programme in terms of energy consumption for cotton.	
Weighted programme time of the 'standard cotton programme at full and partial load' in minutes	136
Programme time of the 'standard cotton programme at full load' in minutes	178
Programme time of the 'standard cotton programme at partial load' in minutes	104
Condensation efficiency class on a scale from G (least efficient) to A (most efficient)	В
Average condensation efficiency of the standard cotton pro- gramme at full load as a percentage	81
Average condensation efficiency of the standard cotton pro- gramme at partial load as a percentage	81
Weighted condensation efficiency for the 'standard cotton pro- gramme at full and partial load'	81
Sound power level in dB	66

Built in applian	ce Y/N
------------------	--------

No

The information given in the chart above is compliant with the EU Commission regulation 392/2012 implementing directive 2009/125/EC.

15. ENVIRONMENTAL CONCERNS

Recycle materials with the symbol $\dot{\zeta}$. Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of appliances marked with the symbol with the household waste. Return the product to your local recycling facility or contact your municipal office.

www.aeg.com/shop



● 136970870-A-382020

