



Tumble dryer

WTH830L5SN

[en]

User manual and installation instructions

Further information and explanations are available online:



Table of contents

1 Safety	. 4
1.1 General information	. 4
1.2 Intended use	
1.3 Restriction on user group	. 4
1.4 Safe installation	. 5
1.5 Safe use	. 7
1.6 Safe cleaning and mainten-	
ance	. 9
2 Preventing material damage	11
3 Environmental protection and saving energy	11
3.1 Disposing of packaging	11
3.2 Saving energy	11
3.3 Energy saving mode	12
4 Installation and connection	12
4.1 Unpacking the appliance	12
4.2 Contents of package	12
4.3 Requirements for the installation location	12
4.4 Aligning the appliance	14
4.5 Connecting the appliance to	14
the electricity supply	14
5 Familiarising yourself with your appliance	15
5.1 Appliance	15
5.2 Control panel	16
·	10
6 Display	17
7 Buttons	19
8 Programmes	20
8.1 Automatic programmes	20
8.2 Timed programmes	21
· =	

Accessories	23
10 Laundry10.1 Preparing the laundry	24 24
11.1 Switching on the appliance 11.2 Setting a programme 11.3 Loading laundry 11.4 Starting the programme 11.5 Adding laundry 11.6 Cancelling the programme 11.7 Unloading the laundry 11.8 Switching off the appliance 11.9 Fluff filter 11.10 Filter system on the base	24 24 24 24 25 25 25 25 25
unit11.11 Condensation container	27 28
12.1 Changing the dryness level 12.2 Adjusting the dryness level	29 29 30
13 Childproof lock	30
lock13.2 Deactivating the childproof	30
lock	30 30
14.1 Overview of the basic settings	30
14.2 Changing the basic set- tings	30
15 Cleaning and servicing	31 31 33

16 Troubleshooting	34
17 Transportation, storage and disposal	37
17.1 Disposing of old appliance	37
18 Customer Service 18.1 Product number (E-Nr.) and production number (FD)	
19 Consumption values	39
20 Technical data	40



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for drying and freshening up fabrics that are washed with water and suitable for dryers.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
 - → "Accessories", Page 23. No other installation method is permitted.
- ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- Call customer services. → Page 37

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

↑ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

► Keep naked flames and ignition sources away from the appli-



△ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

▶ Do not place laundry in this appliance to be dried if the laundry has not been washed first.

- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

★ WARNING – Risk of fire!

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

► Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

en Safety

An ingress of moisture can cause an electric shock.

- ▶ Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

➤ Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appli-

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 20 The function of the appliance may be impaired if the appliance overheats.
- ► Keep the ventilation opening on the appliance clear during operation.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

If you operate the appliance without a fluff guard (e.g. fluff filter, fluff collector, filter mat, etc., depending on appliance specifications), or if the fluff quard is incomplete or defective, this may result in damage to the appliance.

Do not operate the appliance without a fluff guard, or with a fluff guard that is incomplete or defective.

Foam and foam rubber may deform or melt during the drying process.

Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appli-

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

- Operate the appliance in a wellventilated room and keep the ventilation opening on the appliance clear.
- Spin the laundry in the washing machine before drying.
- Observe the program's maximum load capacity. Programmes → Page 20

- After drying, clean the lint screen.
 → "Cleaning the fluff filter",
 Page 25
- Dry the filters in the filter system of the base unit thoroughly after cleaning.
 - → "Filter system on the base unit", Page 27

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode. All displays go out and DIII flashes.

Energy-saving mode ends when you use the appliance again.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the door.
- Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 23

The delivery consists of the following:

- Tumble dryer
- Accompanying documents

4.3 Requirements for the installation location

ATTENTION!

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors. If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

 Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

Installation location	Requirements
On the floor	Place the appliance on a clean, level and firm surface. Align the appliance → Page 14.

Installation loca- Requirements tion


In a washer-dryer stack

Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

- Connection kit with pull-out worktop
 - → Page 23
- Connection kit → Page 23

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-dryer stack on a platform.

Against a wall




Do not trap the hoses and power cord between the wall and the appliance.

4.4 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.


4.5 Connecting the appliance to the electricity supply

- 1. Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data → Page 40.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

- Ventilation opening
- Maintenance flap on the base unit → Page 31
- Fluff filter → Page 25

- Door
- Condensation container → Page 28
- Control panel → Page 16 6

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 1 Programmes → Page 20
- Programme selector

 → Page 24
- 3 Display → Page 17
- 4 Buttons → Page 19

6 Display

The display shows the current settings, options or relevant information. Depending on the programme status, the display shows some information in the $\exists \exists \exists$ area, e.g. $\exists \neg \exists$.



Display	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
1:25	The timed programme is set. → "Timed programmes", Page 21
10h ¹	Program end time → "Buttons", Page 19
<u></u>	 ■ Lights up: The childproof lock is activated. ■ Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 30
_	Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
 	The adjusted dryness level is activated. → "Dryness level", Page 29
	The crease-reduction function is activated. → "Buttons", Page 19
٩	Empty and insert the condensation container. → Page 28
***************************************	Clean the fluff filter \rightarrow Page 25. Clean the filter system on the base unit. \rightarrow Page 27
<u>\$\$\$</u>	Programme status: Drying
<u>\$</u>	Programme status: Iron dry dryness level
<u> </u>	Programme status: Cupboard Dry dryness level
¹ Example	

en Display

Display	Description
0	Programme status: Crease-reduction function
-P-	Programme status: Pause
End	Programme status: Programme end
¹ Example	

7 Buttons

Below is an overview of the buttons and their setting options.

Button	Selection	Description
D00	StartCancelPause	Start, cancel or pause the programme.
c∞ 3 sek.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 30
<u>*</u>	■ 1 ■ 2 ■ 3	Adjust the dryness level. If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level. → "Adjusting the dryness level", Page 30
•	ActivateDeactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 120 minutes to prevent creasing.
(<u>C</u>)	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.

8 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

8.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → Page 29. The dryness level defines how dry or damp the laundry is after the programme ends.

Tips

- Select the dryness level according to the type of fabric or the desired drying result.
 - → "Dryness level", Page 29
- The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Cotton Cupboard Dry Extra	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. The dryness level is not defined in this programme. → "Dryness level", Page 29	7.0
Cotton Cupboard Dry	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. The dryness level is not defined in this programme. → "Dryness level", Page 29	7.0
Cotton Iron Dry	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. The dryness level is not defined in this programme. → "Dryness level", Page 29	7.0
☐ Eco	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Energy-saving programme.	7.0
Easy Care Cupboard Dry Extra	Dry items made of synthetic materials or blended fabrics. The dryness level is not defined in this programme. → "Dryness level", Page 29	3.5

Programme	Description	Max. load (kg)
Easy Care Cupboard Dry	Dry items made of synthetic materials or blended fabrics. The dryness level is not defined in this programme. → "Dryness level", Page 29	3.5
Easy Care Iron Dry	Dry items made of synthetic materials or blended fabrics. The dryness level is not defined in this programme. → "Dryness level", Page 29	3.5
Mix	Dry items made of cotton and synthetics.	3.0
Delicate	Dry delicate items made of satin, synthetics or blended fabrics.	2.0
Sport	Dry self-drying sportswear made of performance fibres, microfibres and synthetics.	1.5
Shirts/Blouses	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics. Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time. Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	1.5
Rapid 40'	Dry items made of synthetics and light cotton.	1.0
Towels	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0

8.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information about programme selection.

en Programmes

Programme	Description	Max. load (kg)
Time Program Cold 30' ©	Dry all types of fabric except for wool and silk. For fluffing or airing clothing that has hardly been worn. Also suitable for drying individual items of laundry. The programme duration is 30 minutes.	3.0
Time Program Warm 30' ©	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry. The programme duration is 30 minutes.	3.0

9 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Some accessories are available in other colours. Contact → "Customer Service", Page 37.

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WTZ20410
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WTZ11400
Wool basket	Dry or air individual woollen items, sports shoes and soft toys.	WMZ20600
Y-distributor	Connect the water outlet hose of an additional appliance to the same siphon outlet.	15000490
Water outlet hose	Drain away excess con- densation directly into the waste water system, without having to regu- larly empty the condens- ation container.	WTZ1110
Filter mat	Spare part to protect against fluff for the base unit's filter system.	12007650

	Use	Order number
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	

10 Laundry

10.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Remove curtain fittings and lead strips
- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket

11 Basic operation

11.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected. → *Page 12*

► Turn the programme selector to a programme.

11.2 Setting a programme

- **1.** Turn the programme selector and set the required programme.
 - → "Programmes", Page 20
- **2.** If required, adjust the programme settings.
 - → "Buttons", Page 19

The programme settings are not saved permanently for the programme.

11.3 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes.

→ "Programmes", Page 20

Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 24
- The drum is empty.
- 1. Open the door.
- 2. Place the laundry in the drum.
- **3.** Close the door.

Ensure that there is no laundry trapped in the door.

11.4 Starting the programme

Requirement: A programme is set.

- → Page 24
- ► Press DII.

- ✓ The display shows the programme duration or the programme end time.
- After the programme has ended, the display shows: "End".

11.5 Adding laundry

After the programme starts, you can remove or add laundry at any time.

- 1. Press DII.
- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press DM

11.6 Cancelling the programme

- 1. Press DII.
- 2. Open the door.
- 3. Remove the laundry. → Page 25

11.7 Unloading the laundry

- 1. Open the door.
- 2. Remove the laundry from the drum.

11.8 Switching off the appliance

► Turn the programme selector to Off .

11.9 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.

Cleaning the fluff filter


If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.


Requirements

- The display shows the following after drving: "End"
- or the display shows the following during operation:

 ...
- 1. Open the door.
- 2. Remove the fluff from the door.




3. Remove the two-part fluff filter.




en Basic operation

4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.


5. Disconnect the two-part fluff filter.




6. Open the two fluff filters.




7. Remove the fluff.




8. Clean the two fluff filters thoroughly under warm, running water and then dry them off.



9. Close the two fluff filters and put them together.



10. Insert the two-part fluff filter.



11. Close the door.

11.10 Filter system on the base unit

During drying, fluff from the laundry is collected in the base unit's filter system. The filter system protects the appliance from fluff.

Cleaning the filter system on the base unit

If the display shows a notification while the appliance is in operation, clean the base unit's filter system.

Notes


- You can clean the filter regularly system even without the notification being shown on the display. It is not necessary to clean after each drying cycle.
- If you do not clean the appliance as described, the appliance's functionality may be impaired.

Requirement: The display shows the following during operation:

.


- **1.** Clean the fluff filter \rightarrow Page 25.
- 2. Open the base unit. → Page 31

3. Carefully remove the filter mat from the retainers.



Ensure that you do not deform or damage the filter mat.


4. Use a soft brush to clean the heat exchanger cover.



Make sure that you remove all dirt from the seal


en Basic operation

Clean the filter mat thoroughly under warm, running water and squeeze it out by hand.



You can remove heavy soiling carefully using a vacuum cleaner. Do not clean the filter mat using cleaning products.

6. Push the filter mat onto the retainers.



Ensure that the cleaned filter mat is not deformed, damaged or inverted when you push it onto the retainers.

Note: You can order the filter mat → *Page 23* as a spare part from customer service.

7. Close the base unit. → Page 32

11.11 Condensation container


Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation container.

Emptying the condensation container


If the drying programme has finished or the display shows a notification while the appliance is in operation, empty the condensation container.

Requirements

- The display shows the following after drying: "End"
- or the display shows the following during operation: 🖺 .
- **1.** Pull out the condensation container, keeping it level.




2. Empty the condensation container.



Make sure that you insert the condensation container before operating the appliance. → Page 29

Inserting the condensation container

 Push the condensation container in as far as it will go.



12 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Programme	Description
Cotton Cup- board Dry Ex- tra Easy Care Cupboard Dry Extra	For multi-layered, thick laundry that does not dry readily.
Cotton Cup- board Dry Easy Care Cupboard Dry	For normal, single- layered laundry.
Cotton Iron Dry Easy Care Iron Dry	For normal, single- layered laundry. The laundry is still slightly damp after the programme ends. To prevent creasing after drying, iron the laundry or hang it up.

12.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- ► Set an automatic programme with the desired dryness level.
 - → Page 20

12.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

- 1. Set an automatic programme with the desired dryness level.
 - → Page 20
- 2. Press .
- ightharpoonup The display shows "1" , "2" or "3" .

13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ► Press on both C 3 sek. buttons for approx. three seconds.
- → The control elements are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power cut.

13.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.


- Press on both cm 3 sek. buttons for approx. three seconds.
 So that the programme currently running is not cancelled, the programme selector must be set to
- ✓ congoes out on the display.

the initial programme.

14 Basic settings

You can configure the basic settings for your appliance to meet your needs.

14.1 Overview of the basic settings



Programme selector with programme positions

- 2 Set the spin speed of the washing machine: 600 (low) to 1800 (high)¹
 The set value increases or decreases the displayed duration of the automatic programmes.
- Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)
- Set the volume of the signal tone emitted when the buttons are pressed:
 0 (off) to 4 (very loud)

14.2 Changing the basic settings

Set the programme selector to position 1. → Page 30

¹ Example

- 2. Press DII and, at the same time, turn the programme selector to position 2.
- ▼ The display shows the current value.
- 3. Use the programme selector to select the required basic setting. → Page 30
- **4.** To change the value, press ①.
- 5. To save the changes, switch off the appliance.

15 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

15.1 Base unit


The base unit is the accessible area at the bottom of the appliance in which you will find the heat exchanger.

Opening the base unit

Requirements


- The appliance has cooled down for 30 minutes.
- The appliance door is closed.

1. Open the maintenance flap.




If you place a cloth beneath the maintenance flap, you can collect the remaining water from the base unit.

2. Open the lever for the heat exchanger cover.



3. Pull out the heat exchanger cover by the handle.




Cleaning the base unit

You can remove any visible dirt in the base unit.

⚠ CAUTION Risk of cutting!


Touching sharp edges on the heat exchanger may lead to cuts.

- ▶ Do not touch the fins on the heat exchanger.
- **1.** Open the base unit \rightarrow Page 31.
- 2. Use a soft brush to clean the heat exchanger cover.




Make sure that you remove all dirt from the seal.

Carefully clean the fins on the heat exchanger with a vacuum cleaner and brush attachment.



Ensure that you vacuum the fins from top to bottom so that they do not become deformed or damaged.

4. Clean the opening with a soft, damp cloth.




5. Close the base unit \rightarrow *Page 32*.


Closing the base unit

Requirement: The base unit is open.


- → "Opening the base unit", Page 31
- 1. Insert the heat exchanger cover by the handle.




2. Close the lever for the heat exchanger.



3. Close the maintenance flap.



2. Clean the moisture sensor with a sponge.



15.2 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.

ATTENTION!

Hard or rough objects may damage the moisture sensor.

► Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

1. Open the door.

16 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting		
The display goes out and DII flashes.	Energy-saving mode is active ► Press DII.		
	The condensation container is full. ► Empty the condensation container. → Page 28		
	The water outlet hose is not connected correctly, or is kinked or trapped. • Check the installation of the water outlet hose.		
	Water outlet hose is blocked. ► Rinse the water outlet hose with tap water.		
	 A foreign object is in the base unit. 1. Open the base unit. → Page 31 2. Remove any foreign objects. 3. Close the base unit. → Page 32 		
®	Fluff filter is soiled. ► Clean the fluff filter. → Page 25		
	Filter system on the base unit is dirty. ► Clean the filter system on the base unit. → Page 27		
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → Page 30		
	 ⑤ is activated. ► Check whether ⑤ is activated. → Page 19 		
The length of the programme changes during the drying cycle.	Not a fault. The programme sequence is optimised electronically. No action required.		

Fault	Cause and troubleshooting
The drying time is too long.	Filter system on the base unit is dirty. ► Clean the filter system on the base unit. → Page 27
	Fluff filter is soiled. ► Clean the fluff filter. → Page 25
	The ambient temperature is lower than 15 °C or higher than 30 °C. ► Ensure that the ambient temperature is between 15 °C and 30 °C.
	The air circulation at the appliance's installation location is insufficient. • Ventilate the appliance's installation location.
	 The appliance's ventilation opening is blocked. Ensure that the ventilation opening of the appliance is kept clear.
	 Heat exchanger is soiled. 1. Open the base unit. → Page 31 2. Clean the heat exchanger. → Page 32 3. Close the base unit. → Page 32
Humming, whirring or pumping noises.	Not a fault. The compressor, compressor ventilation or condensation pump is active. No action required.
The laundry is too damp.	The selected programme is unsuitable for the type of fabric. ► Set a time programme for subsequent drying. → Page 21
	The load is too large. ► Observe the programme's maximum load capacity. → Page 20
	After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling.
	The selected dryness level is unsuitable. ► Change the dryness level. → Page 29
	The dryness level is not adjusted. ► Adjust the dryness level. → Page 30
	The load is too small. ► Set a time programme for subsequent drying. → Page 21

en Troubleshooting

Fault	Cause and troubleshooting		
The laundry is too	The moisture sensor is dirty.		
damp.	► Clean the moisture sensor. → Page 33		
	The appliance has interrupted the drying process due to the condensation container being full. ► Empty the condensation container. → Page 28		
Creasing.	The selected programme is unsuitable for the type of fabric. ► Set a suitable programme. → Page 20		
	The load is unsuitable. ► Observe the programme's maximum load capacity. → Page 20 ► Prepare the laundry. → Page 24		
	The laundry lies in the drum for too long after drying.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.		
	Easy Care fabrics have been dried for too long. ► Change or adjust the dryness level. → Page 29		
	The crease-reduction function is not activated. ► Activate the crease-reduction function. → Page 19		
Water is leaking from the appliance.	Appliance is not correctly aligned. ► Align the appliance. → Page 14		
	The seal for the heat exchanger cover is dirty. ► Clean the seal for the heat exchanger cover. → Page 27		
	Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose.		
	The lever for the heat exchanger cover is not closed correctly. ► Ensure that the lever for the heat exchanger cover is closed correctly. → Page 32		
Condensation collects in the condensation container despite the	Not a fault. The remaining volume of condensation may remain in the condensation container. No action required.		
water outlet hose being connected.	Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose.		

17 Transportation, storage and disposal

17.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from openina.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- ▶ Dispose of the appliance properly.
- Do not damage the tubing of the refrigerant circuit.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner. Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The auideline determines the framework for the return and recycling of used appliances as applicable throughout the FU.

18 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

18.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

19 Consumption values

The **Eco** programme (denoted by the arrow symbol) is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption.

The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values specified for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions.

The expected programme duration/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cotton Cupboard Dry	-1.5	7.0	1400	50	3:15	1.84
Cotton Cupboard Dry	-1.5	3.5	1400	50	2:08	1.16
Cotton Cupboard Dry	-1.5	7.0	1000	60	3:39	2.10
Cotton Cupboard Dry	-1.5	3.5	1000	60	2:21	1.30
Cotton Cupboard Dry	-1.5	7.0	800	70	4:03	2.36
Cotton Cupboard Dry	-1.5	3.5	800	70	2:34	1.44
C Eco	0.0	7.0	1400	50	3:00	1.70
C Eco	0.0	3.5	1400	50	1:53	1.02
C Eco	0.0	7.0	1000	60	3:24	1.96
C Eco	0.0	3.5	1000	60	2:06	1.16
C Eco	0.0	7.0	800	70	3:48	2.22
C Eco	0.0	3.5	800	70	2:19	1.30
Cotton Iron Dry	12.0	7.0	1400	50	2:13	1.26
Cotton Iron Dry	12.0	3.5	1400	50	1:33	0.83
Cotton Iron Dry	12.0	7.0	1000	60	2:37	1.52
Cotton Iron Dry	12.0	3.5	1000	60	1:46	0.97
Cotton Iron Dry	12.0	7.0	800	70	3:01	1.78
Cotton Iron Dry	12.0	3.5	800	70	1:59	1.11

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Easy Care Cupboard Dry	2.0	3.5	800	40	1:14	0.65
Easy Care Cupboard Dry	2.0	3.5	600	50	1:29	0.79

20 Technical data Appliance height 84.2 cm Appliance width 59.8 cm Appliance depth 61.3 cm Appliance depth 65.1 cm with door closed Appliance depth 108.3 cm with door open Weight 46.3 kg Maximum load 7.0 kg 220-240 V. Mains voltage 50 Hz 10 A stallation protection Nominal power 600 W Power consump-Off mode: tion 0.10 W Left-on mode: 0.50 W Ambient temper-Minimum: 5°C ature Maximum: 35 °C Length of the 145 cm power cord

More information about your model can be found online at https://eprel.ec.europa.eu/qr/1352186¹. This web address is linked to the official EU EPREL product database.

Only applies to countries in the European Economic Area









Thank you for buying a Bosch Home Appliance!

Register your new device on MyBosch now and profit directly from:

- · Expert tips & tricks for your appliance
- · Warranty extension options
- Discounts for accessories & spare-parts
- Digital manual and all appliance data at hand
- Easy access to Bosch Home Appliances Service

Free and easy registration – also on mobile phones: **www.bosch-home.com/welcome**



Looking for help? You'll find it here.

Expert advice for your Bosch home appliances, help with problems or a repair from Bosch experts.

Find out everything about the many ways Bosch can support you: **www.bosch-home.com/service**

Contact data of all countries are listed in the attached service directory.

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY www.bosch-home.com

A Bosch Company



Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom