SIEMENS

WQ46B2DPDN

Tumble dryer



EN User manual and installation instructions



Further information and explanations are available online:



Table of contents

1.1 General information	. 4 . 4 . 4	8 Programm 8.1 Automat 8.2 Timed po 9 Accessori
1.5 Safe use 1.6 Safe cleaning and maintenance 2 Preventing material damage	. 7	10 Laundry. 10.1 Prepari 10.2 Care sy labels
3 Environmental protection and saving energy	11 11 11 12	11 Basic op 11.1 Switchin 11.2 Setting 11.3 Saving tings
 4 Installation and connection 4.1 Unpacking the appliance 4.2 Contents of package 4.3 Requirements for the installation location 4.4 Water outlet hose 4.5 Aligning the appliance 4.6 Connecting the appliance to the electricity supply 	12 12 12 12 13 15	11.4 Openin 11.5 Loading 11.6 Starting 11.7 Adding 11.8 Cancell 11.9 Unload 11.10 Put the stands 11.11 Fluff fi 11.12 Conde
5 Familiarising yourself with your appliance	17 17 18 18	12 Dryness 12.1 Changi 12.2 Adjustin 13 Childpro 13.1 Activati
6 Display 7 Buttons	19 21	lock
		14 Wool bas

8 Programmes	24 24 26
9 Accessories	27
10 Laundry	28 28
11.1 Switching on the appliance 11.2 Setting a programme 11.3 Saving the programme settings 11.4 Opening the door 11.5 Loading laundry 11.6 Starting the programme 11.7 Adding laundry 11.8 Cancelling the programme 11.9 Unloading the laundry 11.10 Put the appliance into standby mode 11.11 Fluff filter 11.12 Condensation container	28 28 29 29 29 29 30 30 30 30 31
12 Dryness level 12.1 Changing the dryness level 12.2 Adjusting the dryness level	32 33 33
13 Childproof lock	33
lock 13.2 Deactivating the childproof lock	3333
14 Wool basket 14.1 Inserting the wool basket	33

	Starting a programme with the wool basket	34
14.3	Examples of how to use the wool basket	35
	ome Connect	35
15.2	Setting up the Home Connect app Setting up Home Connect Deactivating Wi-Fi on the	36 36
	applianceActivating Wi-Fi on the ap-	36
15.5	pliance Installing the software up- date	3636
15.615.7	Resetting the appliance network settings	37 37
15.9	Intelligent programme recommendation	37 37 38
16 R	asic settings	38
16 1	Overview of the basic set	30
16.1	Overview of the basic settings	38
16.116.2	Overview of the basic set-	
16.1 16.2 17 A	Overview of the basic settings Changing the basic settings ppliance care	38
16.1 16.2 17 A 17.1	Overview of the basic settings	38 39
16.1 16.2 17 A 17.1 17.2	Overview of the basic settings	38 39 39
16.1 16.2 17 A 17.1 17.2	Overview of the basic settings	38 39 39 39
16.1 16.2 17 A 17.1 17.2 17.3 18 C 18.1 18.2	Overview of the basic settings	38 39 39 39 40 41
16.1 16.2 17 A 17.1 17.2 17.3 18 C 18.1 18.2	Overview of the basic settings	38 39 39 39 40 41 41
16.1 16.2 17 A 17.1 17.2 17.3 18 C 18.1 18.2	Overview of the basic settings	38 39 39 39 40 41
16.1 16.2 17 A 17.1 17.2 17.3 18 C 18.1 18.2 19 Ti di	Overview of the basic settings	38 39 39 39 40 41 41 43

21 Customer Service	
22 Consumption values	49
23 Technical data	
24 Declaration of Conformity 24.1 Statement of Compliance for Great Britain	



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- for drying and freshening up fabrics that are washed with water and suitable for dryers.
- in private households and in enclosed spaces in a domestic environment.
- Up to an altitude of 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- ► Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- ▶ Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an isolating switch must be integrated into the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- ► Never let the power cord come into contact with hot appliance parts or heat sources.
- Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- ➤ Only use adapters and power cords approved by the manufacturer.

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The heavy weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- ► Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
 - → "Accessories", Page 27. No other installation method is permitted.
- ➤ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ► Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- ► Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

⚠ WARNING – Risk of electric shock!

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ▶ Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 47

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ▶ Never expose the appliance to intense heat or humidity.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ► With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

▶ Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

► Keep naked flames and ignition sources away from the appli-



⚠ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

► Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

▶ Do not place laundry in this appliance to be dried if the laundry has not been washed first.

- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand injuries.

▶ Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

△ WARNING – Risk of electric shock!

Improper repairs are dangerous.

- Never make any technical modifications to the appliance or its features.
- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

An ingress of moisture can cause an electric shock.

- ► Before cleaning, pull out the mains plug or switch off the fuse in the fuse box.
- ► Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

➤ Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 24
 The function of the appliance may be impaired if the appliance overheats.
- Keep the ventilation opening on the appliance clear during operation.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked in from the ventilation opening on the appliance during operation and impair the function of the appliance.

- Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

If you operate the appliance without a fluff guard (e.g. fluff filter, fluff collector, filter mat, etc., depending on appliance specifications), or if the fluff guard is incomplete or defective, this may result in damage to the appliance.

Do not operate the appliance without a fluff guard, or with a fluff guard that is incomplete or defective. Foam and foam rubber may deform or melt during the drying process.

Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appliance.

- Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

- Operate the appliance in a wellventilated room and keep the ventilation opening on the appliance clear.
- Spin the laundry in the washing machine before drying.
- For each drying process, use the maximum load for the programs. Programmes → Page 24

- Do not exceed the programme's maximum load capacity. Programmes → Page 24
- After drying, clean the fluff filter.
 → "Cleaning the fluff filter",
 Page 30
- Deactivate Wi-Fi on the appliance if it is not being used.
 - → "Deactivating Wi-Fi on the appliance", Page 36

3.3 Energy saving mode

If you do not use the appliance for a brief period, it automatically switches to energy-saving mode. All displays go out and \triangleright flashes.

Energy-saving mode ends when you use the appliance again.

If you do not use the appliance for an extended period, it automatically switches to standby mode.

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- ► Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the door. → Page 29

- **4.** Remove any accessories from the drum.
- 5. Close the door.

4.2 Contents of package

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

- Do not operate the appliance with incomplete or defective accessories.
- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 27

The delivery consists of the following:

- Tumble dryer
- Accompanying documents
- Wool basket with insert → "Wool basket". Page 33
- Water outlet hose with connection adapter, fixing material and elbow.
 - → "Water outlet hose", Page 13

4.3 Requirements for the installation location

Observe the instructions for the installation location.

ATTENTION!

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

► Tilt the appliance carefully.

Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

 Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

On the floor

Place the appliance on a clean, level and firm surface.

Align the appliance. → Page 15

In a washer-dryer stack


Only use the original connection set from the dryer manufacturer when setting up this appliance in a washerdryer stack.


- Connection kit → Page 27
- Connection kit with pull-out worktop → Page 27

This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine.

Do not place the washer-dryer stack on a platform.

Against a wall





Do not trap the hoses and power cord between the wall and the appliance.

4.4 Water outlet hose

Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation container. Use the water outlet hose to drain away excess condensation directly into the waste water system.

Note

- Operate this appliance using the water outlet hose provided.
 - → Page 13

If you connect the water outlet hose, you do not have to regularly empty the condensation container.

→ "Emptying the condensation container", Page 31

Connecting the water outlet hose

If you do not want to regularly empty the appliance's condensation container, connect the water outlet hose.


ATTENTION!

When operating the appliance without the condensation hose or water outlet hose being connected properly, liquid may leak out of the connecting piece.

Before operating the appliance, connect the condensation hose or water outlet hose properly to the connecting piece.

Requirements


- The appliance and the accessory have been unpacked. → Page 12
- The appliance is installed at the installation location.
- **1.** Pull out the condensation hose from the connecting piece.




The condensation hose is connected to the connecting piece at the factory.

Note: When removing the condensation hose, liquid may leak out of the connecting piece.


2. Push the condensation hose into the holder.



Push the water outlet hose as far as it will go into the connecting piece.



- **4.** Empty the condensation container. → *Page 31*
- **5.** Remove the stopper from the underside ① and insert it in the recess in the top ②.



6. Insert the condensation container.→ Page 32

7. Connect the appliance to the water drain. → Page 15

Tip: To collect condensation in the condensation container again (e.g. if you change where the appliance is located), carry out these steps in reverse order.

Water outlet connection types

ATTENTION!

In the event of a blocked or covered outlet, accumulated wastewater can flow back into the appliance.


 Before operating the appliance, ensure that the wastewater drains away quickly and eliminate any blockages.

Drainage into a siphon.



Secure the connection point with a (12-22 mm) hose clamp.
Secure the water outlet hose with a hose guide at a height of at least 80 cm and no more than 100 cm.


Note: You can use the Y-distributor → Page 27 to connect the water outlet hose of an additional appliance, such as a washing machine, to the same siphon outlet. Drainage into a wash basin.



Push the water outlet hose fully through the elbow and secure it using fixing material.

Secure the elbow at a height of no more than 100 cm.

Drainage into a gully.




Push the water outlet hose fully through the elbow and secure it using fixing material.
Secure the elbow to the gully.

4.5 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.

4.6 Connecting the appliance to the electricity supply

 Insert the mains plug of the appliance's power cable in a socket nearby.

en


The connection details of the appliance can be found under Technical data \rightarrow *Page 51*.

2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

1	Ventilation opening	
2	Fluff filter → Page 30	

4	Condensation container → Page 31

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.



- 1 Programmes → Page 24
- Programme selector

 → Page 28
- Buttons → Page 21 and display → Page 19

5.3 Operating logic

Some areas of the display are buttons and respond to touch. You can activate, deactivate or change settings by pressing the buttons. The activated settings are highlighted in colour on the display.

ATTENTION!

Pressing on the display with force may cause damage.

- Do not apply heavy pressure on the display.
- Do not press on the display using pointed or sharp objects.

Changing a setting value

If you activate certain settings, the display shows selection buttons and you can change the setting value.

Press the selection buttons → Page 21.

The display shows the setting value.


6 Display

The display shows the current settings, options or relevant information.

Depending on the programme status, the display shows some information in the BB:BB area, e.g. End.

Note: Additional functions may be available as a result of software updates. → *Page 36*

If a software update is available, you can find further information in the Home Connect app.



Example: Display

Indicator	Description
0:40 1	Expected programme duration or programme time remaining in hours and minutes.
9.01	Recommendation for the maximum load capacity for the selected program in kg.
(9 10h 1	Program end time → "Buttons", Page 23
=(1)	Shortened programme duration is activated. → "Buttons", Page 23
☆	Save a programme. → "Buttons", Page 22
<u>~</u> ⊚	 Lights up: The childproof lock is activated. Flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 33
¹ Example	-

Indicator	Description
<u></u>	The dryness level is activated. → Page 32
<u> </u>	The dryness level is activated. → Page 32
<u></u> +	The dryness level is activated. → Page 32
ZI ZI	The crease-reduction function is activated. → "Buttons", Page 22
¥.	Gentle drying is activated for delicate fabrics. → Page 23
%	Half load is activated. → Page 23
Ð	You can remove or add laundry, and interrupt the current programme. → Page 29
≌ 〕	Empty and insert the condensation container. → Page 31
≜	Clean the fluff filter → Page 30.
CArE	Run the basic appliance care programme. → Page 39
Hot	The cooling process cools the laundry independently of the programme status for a few minutes while the drum is rotating, in order to avoid damage to the laundry. The cooling process can be cancelled by opening the door. Note: Do not change the set programme.
\$	Change the basic settings. → Page 39
o [*] o	Intelligent programme recommendation is activated. → Page 23
<u></u>	 Lights up: The appliance is connected to your home network via Wi-Fi. Flashes: The appliance is trying to connect to your home network via Wi-Fi.
	→ "Home Connect ", Page 35
	Remote start is activated. → Page 23
Ŋ	Settings that are not available on the appliance have been set via the Home Connect app. You can find more information in the Home Connect app.
Ħ	Programme status: Crease-reduction function
	Programme status: Pause
End	Programme status: Programme end
¹ Example	

7 Buttons

Below is an overview of the buttons and their setting options.

Note: Additional functions may be available as a result of software updates. → *Page* 36

If a software update is available, you can find further information in the Home Connect app.

Button	Selection	Description
	StartCancelPause	Start, cancel or pause the programme. If \blacksquare is displayed, you can pause the programme. If \triangleright is displayed, you can start the programme.
(mains switch)	 Switch on Standby mode Restart the appliance 	Switch on the appliance or put it in standby mode. If the control panel does not respond, press and hold ⊕ for approximately 5 seconds to restart the appliance. → "The display and buttons do not respond.", Page 44
≈ 3 sec.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 33
\$	Multiple selection	To change a setting, press the ∧ or ∨ selection button until the display shows the required setting.

Button	Selection	Description
Basic Settings	Multiple selection	→ "Basic settings", Page 38
Favourite	■ Store ■ Adjust	Press the button for approx. 3 seconds to save your customised programme settings. → "Saving the programme settings", Page 29 If you briefly press the button, you set your saved programme with individual programme settings.
⊕ * Cupboard Dry Plus	ActivateDeactivate	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 32
⊞ Cupboard Dry	ActivateDeactivate	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 32
□ Iron Dry	ActivateDeactivate	The dryness level defines how damp or dry the laundry is after the programme ends. → "Dryness level", Page 32
Anti Crease	ActivateDeactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 120 minutes to prevent creasing.

Button	Selection	Description
varioSpeed	ActivateDeactivate	Activate or deactivate a shorter programme duration.
		Note: The energy consumption increases. This does not impair the drying result.
Low Heat	ActivateDeactivate	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.
Ready in	Up to 24 hours	Set the programme end time. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
Half load	ActivateDeactivate	Dry individual items of laundry or small loads of laundry.
intelligentDry	Activate	After you have washed your laundry in the washing machine, the dryer recommends a suitable programme for drying the laundry. Note: The washing machine must be compatible with Home Connect. The washing machine and dryer must be connected to your home network and registered in your Home Connect app.
Remote Start 🗇	ActivateDeactivate	Activate or deactivate remote start. → Page 37

Button	Selection	Description
	Opening the Home Connect se tings	t-

8 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

Notes

- The laundry's care labels provide you with additional information about programme selection.
 → "Care symbols on the care labels", Page 28
- Additional functions may be available as a result of software updates. → Page 36
 If a software update is available, you can find further information in the Home Connect app.

8.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → *Page 32*. The dryness level defines how dry or damp the laundry is after the programme ends.

Tip: Select the dryness level according to the type of fabric or the desired drying result.

Programme	Description	Max. load (kg)
Cotton	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	9.0
Eco	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Energy-saving programme.	9.0
Easy Care	Dry items made of synthetic materials or blended fabrics.	3.5
Mix	Dry items made of cotton and synthetics.	3.0

Programme	Description	Max. load (kg)
Bed linen	Dry duvet covers, pillowcases and sheets made of cotton. Note: The drum movement is optimised for drying large items of laundry.	3.5
Lingerie	Dry delicate underwear made of lace, Lycra, satin or blended fabrics.	2.0
Hygiene	Dry hard-wearing, heat-resistant fabrics made of cotton or linen. Suitable for increased hygiene requirements.	4.0
Outdoor	Dry weatherproof and outdoor clothing with a membrane coating and water-repellent fabrics.	1.5
Shirts	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics. Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time. Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	1.5
Super 40'	Dry items made of synthetics and light cotton.	1.0
Towels	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0
App programs →=	Select additional programmes directly via the Home Connect app. A description of the programmes can be found in the Home Connect app. Note: Your appliance must be connected to your home network and registered in your Home Connect app. → Page 35	_

8.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Programme	Description	Max. load (kg)
Wool in Basket	Dry items made of wool or containing wool. Note ■ Dry these items only using the wool basket. → Page 33	0.5
Time Program Warm	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry. Note ■ This programme is suitable for drying using the wool basket. → Page 33 If you are using the wool basket, you can also dry fabrics made from wool using this programme.	3.0
App programs →=	Select additional programmes directly via the Home Connect app. A description of the programmes can be found in the Home Connect app. Note: Your appliance must be connected to your home network and registered in your Home Connect app. → Page 35	_

9 Accessories

Use original accessories. These have been made especially for your appliance.

Tip: Some accessories are available in other colours. Contact customer service. → *Page 47*

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WZ27510
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WZ27500
Wool basket	Dry or air individual woollen items, sports shoes and soft toys.	WZ20600
Y-distributor	Connect the water outlet hose of an additional appliance to the same siphon outlet.	15000490
Appliance care product	Spare part for the intensive appliance care function.	00311829
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WZDP20D

10 Laundry

10.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

 Remove all items from any pockets in your laundry before using the appliance.

Note

The appliance and fabrics are protected when you prepare your laundry.

- Brush off sand and soil
- Sort the laundry according to colour and textiles and observe the care labels
- Close all zips, hook and loop fasteners, hooks and eyes
- Remove curtain fittings and lead strips
- Load the laundry unfolded into the drum
- Spin the laundry before drying
- Dry woollen items, sports shoes and soft toys in the wool basket
 → "Wool basket", Page 33

10.2 Care symbols on the care labels

Drying care symbols

Symbol	Fabrics
©	Items made from cotton and linen, e.g. towels, bed linen, underwear
	Items made from synthetic, blended or delicate fabrics, e.g. functional garments, shirts

Symbol	Fabrics
	Do not tumble dry items made from silk, nylon, air- impermeable and rubber- coated fabrics, synthetic curtains

11 Basic operation

11.1 Switching on the appliance

Note: If you switch the appliance on the first time after you have connected it to the electrical system, the switch-on process takes up to one minute.

Requirement: The appliance has been correctly installed and connected. → *Page 12*

► Press U. The switch-on process takes a few seconds.

Note: The lighting for the drum goes out automatically.

11.2 Setting a programme

- Turn the programme selector and set the required programme.
 → "Programmes", Page 24
- The display shows the programme settings.
- Adjust the programme settings.
 → "Buttons", Page 21
 Observe the information about op-

erating logic → *Page 18*. The programme settings are not saved permanently for the programme.

11.3 Saving the programme settings

You can save your individual programme settings as favourites.

Requirement: A programme is set. → *Page 28*


Press and hold Favourite for approx. 3 seconds.

Press **Favourite** to call up the saved programme.


Note: To overwrite the saved programme, repeat the steps above.

11.4 Opening the door

1. Grip under the door handle and pull on the door.



2. Open the door.



11.5 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 24

Requirements

- The laundry is prepared and sorted.
 - → "Laundry", Page 28
- The drum is empty.
- 1. Open the door. → Page 29
- **2.** Place the laundry in the drum.
- Close the door.Ensure that there is no laundry trapped in the door.

11.6 Starting the programme

Requirements

- A programme is set. → Page 28
- The door is closed.
- ► Press 🛮 🖒 .
- The display shows the programme duration or the programme end time.
- ✓ After the programme has ended, the display shows: "End" .

Note: When "Hot" is shown on the display, the appliance cools the laundry.

When "Hot" goes out, the laundry has cooled down.

11.7 Adding laundry

After the programme starts, you can remove or add laundry at any time.

1. Press **□ >** .

The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If you want to avoid or cancel the cooling process, open the door.

- → Page 20
- 2. Open the door. → Page 29

- 3. Add or remove laundry.
- 4. Close the door.
- 5. Start the programme. → Page 29

11.8 Cancelling the programme

- **1.** Press **1 1 .** .
- 2. Open the door. → Page 29
- 3. Remove the laundry. → Page 30

11.9 Unloading the laundry

- 1. Open the door. → Page 29
- **2.** Remove the laundry from the drum.

11.10 Put the appliance into standby mode

► Press 🖰.

11.11 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.

Cleaning the fluff filter


If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.


Requirements

- The display shows the following after drying: "End"
- or the display shows the following during operation:
- 1. Open the door. → Page 29
- **2.** Remove the fluff from the inside of the door.

3. Remove the two-part fluff filter.




4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.

5. Disconnect the two-part fluff filter.




6. Open the two fluff filters ① and remove the fluff ②.




Dispose of the fluff with the household waste in order to prevent the water from being contaminated with microplastics.


Clean the two fluff filters thoroughly under warm, running water and then dry them off.



8. Close the two fluff filters and put them together.



9. Insert the two-part fluff filter.



10. Close the door.

11.12 Condensation container

Condensation that forms in the appliance as it dries the laundry is collected by default in the condensation container.

Note: Operate this appliance using the water outlet hose provided.

→ Page 13

If you connect the water outlet hose, you do not have to regularly empty the condensation container.

→ "Emptying the condensation container", Page 31


Emptying the condensation container

If the drying programme has finished or the display shows a notification while the appliance is in operation, empty the condensation container.


Requirements

- The display shows the following after drying: "End"
- or the display shows the following during operation: 🖦 .

1. Pull out the condensation container, keeping it level.




2. Empty the condensation container.



Check the condensation container filter regularly and clean the filter if it is dirty. \rightarrow *Page 41* Make sure that you insert the condensation container before operating the appliance. \rightarrow *Page 32*

Inserting the condensation container

► Push the condensation container in as far as it will go.



12 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Description
⊕ †	For multi-layered, thick laundry that does not dry readily.
I	For normal, single- layered laundry.
	For normal, single- layered laundry. The laundry is still slightly damp after the programme ends. To prevent creasing after drying, iron the laundry or hang it up.

12.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

- Set an automatic programme.
 → Page 24
- The display shows the specified dryness level.
- 2. Press Cupboard Dry , Cupboard Dry Plus or Iron Dry .

12.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

Note: You can also adjust the dryness level in the basic settings.

- Set an automatic programme.
 → Page 24
- The display shows the specified dryness level.
- Press and hold

 ☐ Cupboard Dry ,
 ☐ Cupboard Dry Plus or
 ☐ Iron
 ☐ Dry for approx. 3 seconds.
- ▼ The display shows "0", "1", "2" or "3".
- **4.** Press and hold the selected drying target for approx. 3 seconds to return to the automatic programme.

13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ▶ Press and hold ➡ 3 sec. for approx. 3 seconds.
- The control elements are locked.
- The childproof lock also remains activated when the appliance is in standby mode and in the event of a power cut.

13.2 Deactivating the childproof lock

Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ► Press and hold **3 sec.** for approx. 3 seconds.
- ✓ so goes out on the display.


14 Wool basket

Use the wool basket to gently dry delicate fabrics, soft toys or sports shoes in a stationary position.


14.1 Inserting the wool basket

1. Open the door. Ensure that the drum is empty.

Insert the feet of the wool basket into the holes from the door opening.



3. Insert the tab on the front of the wool basket into the upper hooks.



14.2 Starting a programme with the wool basket


ATTENTION!

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Requirement: The wool basket is inserted into the appliance. \rightarrow *Page 33*

 Place the laundry into the wool basket, either directly or using the insert. → Page 35



- 2. Close the door.
- **3.** Set a programme that is suitable for drying with the wool basket.

Observe the programme description. → Page 26

4. If required, adjust the duration of the programme.

Observe the recommended programme duration for items of laundry in the wool basket:

Laundry item	Programme duration in hours:minutes
Thin woollen pullover	Approx. 1:20
Thick woollen pullover	Approx. 1:30 - 3:00
Skirt	Approx. 1:00 - 1:30
Trousers	Approx. 1:00 - 1:30
Gloves	Approx. 0:30
Sports shoes	Approx. 1:30/ max. 2:00 with airing

Tip: Increase the programme duration for thick or multi-layered items of laundry.

5. Start the programme. → Page 29

6. Remove the wool basket once the programme has ended.

14.3 Examples of how to use the wool basket

ATTENTION!

If items of laundry in the wool basket touch the rotating drum or the ribs of the drum, the laundry may cause material damage and damage to the appliance.

Place the items of laundry in the insert or wool basket such that they do not touch the drum or the ribs of the drum.

Example

Use


Trousers or skirt



Place the items of laundry unfolded into the insert.

Note: Spin the laundry before drying.

Pullover



Example

haaa




Use

Lift the tongues of the shoes. Remove the insoles or heel cushions. Place a rolled-up hand towel in the wool basket to create an inclined surface. Place the shoes on the towel with the heels facing down.

Note: Do not use the insert. Do not dry leather shoes or shoes with leather parts.

Soft toys



Place the soft toy in the wool basket.

Note: Do not use the insert. If you place numerous or small soft toys in the wool basket, make sure they do not fall out.

15 Home Connect

This appliance is network-capable. Connecting your appliance to a mobile device lets you control its functions via the Home Connect app, adjust its basic settings and monitor its operating status.

The Home Connect services are not available in every country. The availability of the Home Connect function depends on the availability of

Home Connect services in your country. You can find information about this at: www.home-connect.com.

The Home Connect app guides you through the entire login process. Follow the instructions in the Home Connect app to configure the settings.

Tip: Please also follow the instructions in the Home Connect app.

Notes

- Please note the safety precautions in this instruction manual and make sure that they are also observed when operating the appliance via the Home Connect app. → "Safety", Page 4
- Operating the appliance on the appliance itself always takes priority.
 During this time it is not possible to operate the appliance using the Home Connect app.

15.1 Setting up the Home Connect app

- 1. Install the Home Connect app on your mobile device.
- Start the Home Connect app and set up access for Home Connect.
 The Home Connect app guides you through the entire login process.

15.2 Setting up Home Connect

Requirements

- The Home Connect app has been installed on your mobile device.
- The appliance is receiving signals from the WLAN home network (Wi-Fi) at its installation location.
- Press and hold Remote Start ☐ for approx. 3 seconds.
- **2.** Follow the instructions in the Home Connect app.

15.3 Deactivating Wi-Fi on the appliance

- Press and hold Remote Start ☐ for approx. 3 seconds.
- 2. Press **Remote Start** The repeatedly until the display shows "on".
- **3.** Press **□** b to deactivate the Wi-Fi.
- ✓ The display shows "oFF".

Note: To exit the Home Connect settings, press and hold **Remote Start** □ for approx. 3 seconds.

15.4 Activating Wi-Fi on the appliance

- Press and hold Remote Start ☐ for approx. 3 seconds.
- 2. Press **Remote Start** T repeatedly until the display shows "oFF".
- **3.** Press **□** b to activate the Wi-Fi.
- ▼ The display shows "on".

Notes

- If the Wi-Fi is activated, the display alternately shows "on" and the signal strength of the Wi-Fi connection.
- To exit the Home Connect settings, press and hold Remote Start ☐ for approx. 3 seconds.

15.5 Installing the software update

Note: If a software update is available, a message appears in the Home Connect app.

- To install the software update, follow the instructions in the Home Connect app.
- ▼ The control panel is partially locked during the installation.

In the event of a malfunction, installation may take up to 40 minutes. Do not reset the network settings or the appliance to the factory settings.

15.6 Resetting the appliance network settings

- Press and hold Remote Start ☐ for approx. 3 seconds.
- 2. Press **Remote Start** The repeatedly until the display shows "rES".
- **3.** Press and hold $\mathbb{I} \triangleright$ for approx. 3 seconds.
- ✓ The network settings are reset.

15.7 Remote start

Enable the appliance for remote start via the Home Connect app.

Note

Remote start will be deactivated in the following circumstances:

- The appliance door is opened.
- II > is pressed.
- Remote Start □ is pressed.
- Following a power cut.

Activating remote start

Requirement: The appliance door is closed.

- ▶ Press Remote Start □ .
- In lights up and the appliance is enabled for remote start via the Home Connect app.

Deactivating remote start

- ▶ Press Remote Start □ .

15.8 Intelligent programme recommendation

When you activate the intelligent programme recommendation, your appliance recommends a suitable pro-

gramme for drying the laundry once you have washed your laundry in the washing machine.

Intelligent programme recommendation

Requirements

- Your washing machine has the Home Connect function.
- Your washing machine and your dryer must be connected to your home network and registered in your Home Connect app.
- 1. Press intelligentDry .
- The appliance detects a suitable programme. To cancel the process, set a different programme or switch the appliance to standby mode.
- If the appliance finds a suitable programme, the display for the programme lights up and the programme information is displayed.
- If the appliance does not find a suitable programme, a signal tone sounds and the display shows "--".
- **2.** Press **1 >** .

15.9 Remote diagnostics

Customer Service can use Remote Diagnostics to access your appliance if you contact them, have your appliance connected to the Home Connect server and if Remote Diagnostics is available in the country in which you are using the appliance.

Tip: For further information and details about the availability of Remote Diagnostics in your country, please visit the service/support section of your local website: www.home-connect.com.

15.10 Data protection

Please see the information on data protection.

The first time your appliance is registered on a home network connected to the Internet, your appliance will transmit the following types of data to the Home Connect server (initial registration):

- Unique appliance identification (consisting of appliance codes as well as the MAC address of the Wi-Fi communication module installed).
- Security certificate of the Wi-Fi communication module (to ensure a secure data connection).
- The current software and hardware version of your appliance.
- Status of any previous reset to factory settings.

This initial registration prepares the Home Connect functions for use and is only required when you want to use the Home Connect functions for the first time

Note: Please note that the Home Connect functions can only be utilised with the Home Connect app. Information on data protection can be retrieved in the Home Connect app.

16 Basic settings

You can configure the basic settings for your appliance to meet your needs.


Note: You can also adjust the basic settings in the Home Connect app.

16.1 Overview of the basic settings

Note: Additional functions may be available as a result of software updates.

→ "Installing the software update", Page 36

If a software update is available, you can find further information in the Home Connect app.



Programme selector with programme positions

- Set the volume of the signal at the end of the programme: 0 (off) to 4 (very loud)
- Set the volume of the signal tone emitted when the buttons are pressed:
 0 (off) to 4 (very loud)
- 3 Set the display brightness: 1 (low) to 4 (very high)
- 4 Adjust the dryness level

 → Page 32:
 0 (dry) to 3 (driest)

6

- 5 Start the basic (CP1) or intensive (CP2) appliance care programme.

 → "Appliance care", Page 39
 - Display the number of started programmes (PC).
- Restore the appliance to the factory settings (rES).

16.2 Changing the basic settings

- 1. To call up the basic settings, press **Basic Settings**.
- Use the programme selector to select the required basic setting.
 → Page 38
- 3. Adjust the basic setting:
 - To change the value, press ∧ or ∨.
 - To reset the appliance to the factory settings, press and hold

 □ ▷ for approx. 3 seconds.
- 4. To exit the basic settings, press **Basic Settings**.

17 Appliance care

The appliance offers cleaning programmes for basic and intensive appliance care.

To remove light dirt deposits in the appliance, you can run the basic appliance care programme when the display shows "CArE" after a longer period of use.

Note: The basic appliance care programme runs for approximately 1 hour.

To remove any stubborn dirt deposits in the appliance and odours after a downtime of more than one month, you can run the intensive appliance care programme.

Notes

- The intensive appliance care programme runs for approximately 4 hours and must not be cancelled.
- When you run the intensive appliance care programme, you need the original appliance care product → Page 27.

17.1 Preparing for appliance care

Preparing the appliance


Requirement: The drum is empty.

- 1. Put the appliance into standby mode. → Page 30
- **2.** Clean the fluff filter \rightarrow Page 30.
- Empty the condensation container.
 → Page 31

Preparing the condensation container

If you drain the condensation using the water outlet hose, prepare the condensation container.

 Remove the stopper from the recess in the top ① and insert it in the underside ②.



2. Clean the filter in the condensation container.

17.2 Running the basic appliance care programme

Requirement: The appliance care is prepared. → *Page 39*

 Pour approx. 1.5 litres of hot mains water into the condensation container.

Hold the filled condensation container level so that no liquid spills out.

- 2. Insert the condensation container so that it locks into place.
- **3.** Switch on the appliance.
- Press Basic Settings .
- Set the programme selector to position 5. → Page 38
- → "CP1" and the programme duration alternate on the display.
- **6.** Press **1 >** .
- The appliance care programme starts and a signal tone sounds.
- "End" appears on the display and a signal tone sounds once the appliance care programme has ended.
- Empty the condensation container.
 → Page 31
- 8. If you drain the condensation using the water outlet hose, remove the stopper from the underside of the condensation container land insert it into the recess in the top of the condensation container.
 - → Page 39
- **9.** Insert the condensation container so that it locks into place.
- **10.** Put the appliance into standby mode. → *Page 30*

17.3 Running the intensive appliance care programme

Starting the intensive appliance care programme

Requirement: The appliance care is prepared. → *Page 39*

 Pour a bottle of the appliance care product and approx. 1.5 litres of hot mains water into the condensation container.

Hold the filled condensation container level so that no liquid spills out.

- Insert the condensation container so that it locks into place.
- **3.** Switch on the appliance.
- 4. Press Basic Settings.
- Set the programme selector to position 5. → Page 38
- → "CP1" and the programme duration alternate on the display.
- 6. Press ✓.
- → "CP2" and the programme duration alternate on the display.
- **7.** Press **□ >** .
- ▼ The appliance care programme starts and a signal tone sounds.
- After around 3 hours, the appliance pauses the appliance care programme and the remaining programme duration flashes on the display.
- 8. Empty the condensation container.→ Page 31
- Pour approx. 1.5 litres of hot mains water into the condensation container.
- 10. Carefully swivel the condensation container horizontally and empty it to rinse out any remaining appliance care product.

Continuing the intensive appliance care programme

- Pour approx. 1.5 litres of hot mains water into the condensation container.
 - Hold the filled condensation container level so that no liquid spills out.
- 2. Insert the condensation container so that it locks into place.
- **3.** Press **1 1 1 .**
- The appliance care programme continues.

- "End" appears on the display and a signal tone sounds once the appliance care programme has ended.
- **4.** Empty the condensation container. → *Page 31*
- 5. If you drain the condensation using the water outlet hose, remove the stopper from the underside of the condensation container land insert it into the recess in the top of the condensation container.
 - → Page 39
- **6.** Put the appliance into standby mode. → *Page 30*

18 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

18.1 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor


Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.

ATTENTION!

Hard or rough objects may damage the moisture sensor.

Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning. **Note:** If you do not clean the appliance as described, the appliance's functionality may be impaired.

- 1. Open the door.
- **2.** Clean the moisture sensor with a sponge.




18.2 Condensation container filter

During drying, fluff from the laundry gets into the condensation. The filter in the condensation container protects the appliance from fluff.

Clean the filter for the condensation tank.


The filter is cleaned automatically when the condensation container is emptied. Check the filter regularly and clean the filter if it is dirty.

- Empty the condensation container.
 → Page 31
- 2. Remove the filter.



en

- 3. Clean the filter under warm, running water or in the dishwasher.
- 4. Slide in the filter as far as it will go.



5. Insert the condensation container.→ Page 32

19 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.

. WARNING

Risk of electric shock!

Improper repairs are dangerous.

- ▶ Never make any technical modifications to the appliance or its features.
- Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- ▶ If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting			
The display goes out and $\mathbb{I} \triangleright$ flashes.	Energy-saving mode is active ► Press □ ▷ .			
"Hot" and the drum rotates.	Not a fault. The cooling process is active. No action required.			
	Note: Do not change the programme during the cooling process. The cooling process takes up to 10 minutes.			
and programme terminated.	The condensation container is full. ► Empty the condensation container. → Page 31			
	The water outlet hose is not connected correctly, or is kinked or trapped. ► Check the installation of the water outlet hose. → Page 13			
	Water outlet hose is blocked. ► Rinse the water outlet hose with tap water.			
	The filter for the condensation tank is soiled. ► Clean the filter for the condensation container. → Page 41			
"CArE"	The basic appliance care programme should be run. ► Run the basic appliance care programme → Page 39.			
	Fluff filter is soiled. ► Clean the fluff filter. → Page 30			

Fault	Cause and troubleshooting			
The display and buttons do not respond.	 Software fault. 1. To restart the appliance, press and hold of for approximately 5 seconds. 2. If the fault occurs again, disconnect the appliance from the power supply for at least 30 seconds. Unplug the appliance from the mains or switch off the circuit breaker in the fuse box. 			
Home Connect is not working properly.	Different causes are possible. 1. Reset the appliance network settings. → Page 37 2. Set up Home Connect again. → Page 36 ► Go to www.home-connect.com.			
The programme does not start.	Childproof lock is activated. ► Deactivate the childproof lock. → Page 33			
	Ready in is activated. ► Check whether Ready in is activated. → Page 23			
The length of the programme changes during the drying cycle.	Not a fault. The programme sequence is optimised electronically. No action required.			
The drying time is too long.	Fluff filter is soiled. ► Clean the fluff filter. → Page 30			
	The ambient temperature is lower than 15 °C or higher than 30 °C. ► Ensure that the ambient temperature is between 15 °C and 30 °C.			
	The air circulation at the appliance's installation location is insufficient. Ventilate the appliance's installation location.			
	Insufficient condensation for the automatic self-cleaning when permanently drying small loads of laundry. ▶ Regularly dry a load weighing more than 3 kg of damp laundry until the programme ends.			
	The appliance's ventilation opening is blocked. ► Ensure that the ventilation opening of the appliance is kept clear.			
	Heat exchanger is soiled. ► Run the basic appliance care programme → Page 39.			
Humming, whirring or pumping noises.	Not a fault. The compressor, compressor ventilation or condensation pump is active. No action required.			

	er
Fault	Cause and troubleshooting
The laundry is too damp.	The selected programme is unsuitable for the type of fabric. ► Set a time programme for subsequent drying. → Page 26
	The load is too large. ► Observe the programme's maximum load capacity. → Page 24
	 After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling.
	The selected dryness level is unsuitable. ► Change the dryness level. → Page 33
	The dryness level is not adjusted. ► Adjust the dryness level. → Page 33
	The load is too small. ► Set a time programme for subsequent drying. → Page 26
	The moisture sensor is dirty. ► Clean the moisture sensor. → Page 41
	The appliance has interrupted the drying process due to the condensation container being full. ► Empty the condensation container. → Page 31
Creasing.	The selected programme is unsuitable for the type of fabric. ▶ Set a suitable programme. → Page 24
	The load is unsuitable. ► Observe the programme's maximum load capacity. → Page 24
	Prepare the laundry. → Page 28
	The laundry lies in the drum for too long after drying.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.
	Easy Care fabrics have been dried for too long. ► Change or adjust the dryness level. → Page 32
	The crease-reduction function is not activated. ► Activate the crease-reduction function. → Page 21

en

Fault	Cause and troubleshooting		
Water is leaking from the appliance.	Appliance is not correctly aligned. ► Align the appliance. → Page 15		
	Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose. → Page 13		
Condensation collects in the condensation container despite the	Not a fault. The remaining volume of condensation may remain in the condensation container. No action required.		
water outlet hose being connected.	Water outlet hose is not connected correctly. ► Check the installation of the water outlet hose. → Page 13		
Odours have formed in the appliance.	Stubborn dirt in the appliance or an extended appliance downtime of more than one month. ► Run the intensive appliance care programme. → Page 39		

20 Transportation, storage and disposal

20.1 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- Dispose of the appliance properly.
- ► Do not damage the tubing of the refrigerant circuit.
- Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

 Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

21 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information about the warranty period and the warranty conditions in your country is available via the QR code on the enclosed document on service contacts and warranty conditions, from our customer service or on our website.

If you contact Customer Service, you will require the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) of your appliance.

You can find the contact details for our customer service via the QR code on the enclosed document on service contacts and warranty conditions or on our website.

21.1 Product number (E-Nr.), production number (FD) and consecutive numbering (Z-Nr.)

You can find the product number (E-Nr.), the production number (FD) and the consecutive numbering (Z-Nr.) on the appliance's rating plate.

Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

22 Consumption values

The **Eco** programme is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption. This programme serves to assess compliance with Regulations (EU) 2023/2533 and (EU) 2023/2534. It corresponds to the "standard cotton programme" within the meaning of Regulation (EU) No 392/2012 and within the meaning of Annex I, point 1.1 of Regulation (EU) No 932/2012. The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values specified for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions. The expected programme duration/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cotton + ⊞ ⁺ Cup- board Dry Plus	-3.0	9.0	1400	50	4:42	1.47
Cotton + ⊞ ⁺ Cup- board Dry Plus	-3.0	4.5	1400	50	3:35	1.05
Cotton + ⊞* Cup- board Dry Plus	-3.0	9.0	1000	60	5:12	1.68
Cotton + ⊞* Cup- board Dry Plus	-3.0	4.5	1000	60	3:52	1.16
Cotton + ⊞ ⁺ Cup- board Dry Plus	-3.0	9.0	800	70	5:43	1.89
Cotton + ⊞* Cup- board Dry Plus	-3.0	4.5	800	70	4:09	1.26

¹ The acoustical noise emissions during the drying cycle are 59 dB.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Programm e duration (h:min)	Energy con- sump- tion (kWh/ cycle)		
Cotton + ⊞ Cup- board Dry	-1.5	9.0	1400	50	4:13	1.39		
Cotton + E Cup- board Dry	-1.5	4.5	1400	50	3:03	0.90		
Cotton + ⊞ Cup- board Dry	-1.5	9.0	1000	60	4:43	1.59		
Cotton + ⊞ Cup- board Dry	-1.5	4.5	1000	60	3:19	0.99		
Cotton + ⊞ Cup- board Dry	-1.5	9.0	800	70	5:12	1.79		
Cotton + ⊞ Cup- board Dry	-1.5	4.5	800	70	3:35	1.09		
Eco	0.0	9.0	1400	50	3:53	1.23		
Eco	0.0	4.5	1400	50	2:22	0.65		
Eco ¹	0.0	9.0	1000	60	4:25	1.44		
Eco	0.0	4.5	1000	60	2:40	0.76		
Eco	0.0	9.0	800	70	4:57	1.65		
Eco	0.0	4.5	800	70	2:58	0.87		
Cotton + 🕮 Iron Dry	12.0	9.0	1400	50	2:42	0.83		
Cotton + 🕮 Iron Dry	12.0	4.5	1400	50	1:44	0.49		
Cotton + 🕮 Iron Dry	12.0	9.0	1000	60	3:12	1.04		
Cotton + 🕮 Iron Dry	12.0	4.5	1000	60	2:01	0.59		
Cotton + 🕮 Iron Dry	12.0	9.0	800	70	3:43	1.25		
Cotton + 🕮 Iron Dry	12.0	4.5	800	70	2:18	0.69		
Easy Care + ⊞ ⁺ Cupboard Dry Plus	0.0	3.5	800	40	1:41	0.45		
Easy Care + ⊞ ⁺ Cupboard Dry Plus	0.0	3.5	600	50	1:57	0.53		
¹ The acoustical noise emissions during the drying cycle are 59 dB.								

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)			
Easy Care + 🗉 Cupboard Dry	2.0	3.5	800	40	1:22	0.38			
Easy Care + 🗉 Cupboard Dry	2.0	3.5	600	50	1:38	0.46			
Easy Care + 🕮 Iron Dry	12.0	3.5	800	40	1:04	0.37			
Easy Care + 🕮 Iron Dry	12.0	3.5	600	50	1:20	0.46			
Lingerie	0.0	2.0	_	-	1:17	0.35			
Wool in Basket	0.0	0.5	-	-	2:00	0.99			
¹ The acoustical noise emissions during the drying cycle are 59 dB.									

23 Technica	l data
Appliance height	84.2 cm
Appliance width	59.8 cm
Appliance depth	61.3 cm
Appliance depth with door closed	66.5 cm
Appliance depth with door open	110.5 cm
Weight	56.2 kg
Maximum load	9.0 kg
Mains voltage	220-240 V, 50 Hz
■ Minimum installation protection	10 A
Nominal power	800 W

Power consumption	Standby mode: 0.30 WLeft-on mode: 0.30 W
Ambient temperature	Minimum:5 °CMaximum:35 °C
Length of the power cord	145 cm

This product contains light sources from energy efficiency class F. These light sources are available as a spare part and must only be replaced by trained specialist staff.

More information about your model can be found online at https://eprel.ec.europa.eu/qr/2274314¹.

This web address is linked to the official EU EPREL product database.

¹ Only applies to countries in the European Economic Area. This website address is available from 1st July 2025.

23.1 Information regarding Free and Open Source Software

This product includes software components that are licensed by the copyright holders as free or open source software.

The applicable licence information is stored on your home appliance. You can also access the applicable licence information via your Home Connect app: "Profile -> Legal information -> Licence Information". You can download the licence information on the brand product website. (Please search on the product website for your appliance model and additional documents). Alternatively, you can request the relevant information from oss-request@bshq.com or BSH Hausger-

request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str. 34, 81739 Munich, Germany.

The source code will be made available to you on request.

Please send your request to oss-request@bshg.com or BSH Hausgeräte GmbH, Carl-Wery-Str.34, 81739 Munich, Germany.

Subject: "OSSREQUEST"

The cost of performing your request will be charged to you. This offer is valid for three years from the date of purchase or at least as long as we offer support and spare parts for the relevant appliance.

24 Declaration of Conformity

BSH Hausgeräte GmbH hereby declares that the appliance with Home Connect functionality conforms to the essential requirements and other relevant provisions of Directive 2014/53/EU.

A detailed RED Declaration of Conformity can be found online at siemens-home.bsh-group.com among the additional documents on the product page for your appliance.

 ϵ

Hereby, BSH Hausgeräte GmbH declares that the appliance with Home Connect functionality is in compliance with relevant statutory requirements.²

A detailed Declaration of Conformity can be found online at siemens-home.bsh-group.com/uk/ among the additional documents on the product page for your appliance.²

UK CA

2.4 GHz band (2400-2483.5 MHz): Max. 100 mW 5-GHz band (5150-5350 MHz + 5470-5725 MHz): max. 150 mW

Depending on the appliance specifications

Only applies to Great Britain

	BE	BG	CZ	DK	DE	EE	ΙE	EL	ES	
	FR	HR	IT	CY	LI	LV	LT	LU	HU	
	MT	NL	AT	PL	PT	RO	SI	SK	Fl	
	SE	NO	СН	TR	IS	UK (NI)				
5 GHz	5 GHz WLAN (Wi-Fi): For indoor use only.									
Al	BA	M	D	MF	MK	RS	UK		UA	
5 GHz	5 GHz WI AN (Wi Fi): For indoor use only									

5 GHz WLAN (Wi-Fi): For indoor use only.

24.1 Statement of Compliance for Great Britain

The full Statement of Compliance according to the Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023 can be found online at www.siemens-home.bsh-group.com/uk/home among the additional documents on the product page for your appliance.

Product type

This statement of compliance covers the products described in this information for use whose model identifier group is seen on the title page. The full model identifier is made up of the characters before the slash in the product number (E no.) which can be found on the rating plate. Alternatively, you can also find the model identifier in the first line of the UK Energy Label.

Name and address of manufacturer

BSH Hausgeräte GmbH, Carl-Wery-Strasse 34, 81739 München, Germany

This statement of compliance is prepared by the manufacturer.

The manufacturer, BSH Hausgeräte GmbH deems that it has complied with

- provision 5.1-1 of ETSI EN 303 645 v2.1.1 and, where relevant, provision 5.1-2 of ETSI EN 303 645 v2.1.1;
- provision 5.2-1 of ETSI EN 303 645 v2.1.1;
- provision 5.3-13 of ETSI EN 303 645 v2.1.1.

Support period

BSH Hausgeräte GmbH will provide security updates that are necessary to maintain the main functions free of charge until at least 28/02/2034.





EN Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com



9002002770

(050324)