



#### Forget pre soaking, zone in on spotless


The 800 SprayZone Dishwasher intensively cleans cookware, with three-times better cleaning performance than the standard. No pre-soaking is needed. Powerful water pressure removes even baked-on food and grease residue, leaving dishes spotless every time.

### Product Benefits & Features



#### SprayZone, an intense clean

Thanks to the SprayZone function, pots and pans are given intensive cleaning treatment. The powerful water pressure brilliantly cleans everything placed within the dedicated space. It's three-times better than the standard, so all your dishes are taken care of.



#### SatelliteClean®. Complete cleaning. Without using extra water

Dishes come out spotless with SatelliteClean®—it performs up to 3x better than the standard dishwasher. Thanks to the double-rotating arm that continuously changes the angle of the spray, even bulky items are deeply cleaned.

#### Sustainable dishwashing made easy

Sustainable choices made easy. Use the QuickSelect touchscreen slider to select your preferred cycle time and the Ecometer displays the most sustainable program to save energy and water through intuitive green bars.



#### Silent feedback, Beam on Floor

The Beam on Floor illuminated feedback system keeps your kitchen quiet. Instead of a loud beep that can be drowned out by background noise, our dishwasher clearly tells you its status by projecting a dot on the floor. Red when it's running, and green when it's complete.



#### QuickLift - change the basket height even when fully loaded

Whether loading or removing dishes do it comfortably with the QuickLift basket. Even when the upper basket is fully flooded, the QuickLift system allows you to quickly raise and lower your rack to fit dishes and kitchen tools of different shapes and sizes.

- XXL tub
- Auto Off function
- Touch control for programs and functions selection
- Drying system: AirDry Technology
- SprayZone
- Cutlery basket
- Water sensor detects the level of dirt and adjusts water consumption
- Dual safety - Floating switch
- FlexiSpray Satellite spray arm
- Ceiling sprayarm
- Height adjustable upper basket, even when fully loaded
- Upper basket with 12 wine glass soft grips, 2 Foldable racks, 2 Foldable wires for glasses, 4 Soft Spikes, Foldable cup shelves, Stainless steel handle Electrolux
- Lower basket with 4 foldable tines, SprayZone, Stainless steel handle
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
- Delay Start

**Product Specification**

Installation	FI	Cleaning performance index3 digitE20	1.121
Rated capacity psE20	13	Drying performance index 3 digitE20	1.061
Energy efficiency class, legal (E20)	B	Weighted average energy consumption / 100 cycles, kWh (E20)	63
Airborne acoustical noise emissions, dBA re 1 pW	43	Water consumption / cycle IE20	10.9
Door colour	None	Hinges	Sliding
XXL-Tub	Yes	Connected load, W	1550-2200
Dimensions_Dishwasher_FSBU_DK	820-900x600x560	Cord length, m	16
Number of programs	8	Outlet hose length, cm	180
Number of temperatures	4	Required fuse (A)	10
Dimensions HxWxD in mm	818x596x560	Inlet hose length, cm	180
Airborne acoustical noise emission class	B	Inlet hose type	Aqua control
Depth open door	1230	Anti-flood device	Floating switch
Nordic_DW_CutleryType	Cutlery basket	Water supply	Cold or Hot
Nordic_DW_QuickSelect	Level 3	Upper spray arm	Standard spray arm
Nordic_DW_SprayZone	Yes	Lower spray arm	Satellite spray arm with Spray Zone
Nordic_DW_SoftGrips	12 SoftGrip holders	Options	GlassCare, SprayZone, XtraPower
Nordic_DW_SoftSpikes	4 SoftSpikes holders	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
Nordic_DW_GlassCare2G	No	Installation in height	None
Beam on floor	Red&Green	Nordic_DW_DoorPanelHeight	670-825
Interior light	No	Nordic_DW_DoorPanelWeight	15-10
Nordic_DW_DoorFitKit	No	Indicator program	LED Display
		Installation type	Built_In
		Net weight, kg	37.28

