Delicate glasses are in good hands
Glasses need a little extra tender loving care, especially when getting washed. Good thing the upper basket in the 700 Pro series dishwasher has SoftGrips that securely yet gently hold your glasses. While SoftSpikes make sure they don't get scratched, or worse break.

Product Benefits & Features

Delicate glasses protected with SoftGrips and SoftSpikes
With SoftGrips and SoftSpikes you no longer need to spend time handwashing delicate glasses. The soft material gently holds glasses securely in place and protects them from cracks and breakage.

Delicate glasses protected with SoftGrips and SoftSpikes
With SoftGrips and SoftSpikes you no longer need to spend time handwashing delicate glasses. The soft material gently holds glasses securely in place and protects them from cracks and breakage.

All your cutlery, washed in one go with MaxiFlex
The MaxiFlex drawer is designed to fit cutlery and utensils of different shapes and sizes. Whether large or awkwardly shaped, the customisable dividers and deep drawer mean everything can be loaded with ease.

Sustainable dishwashing made easy
Sustainable choices made easy. Use the QuickSelect touchscreen slider to select your preferred cycle time and the Ecometer displays the most sustainable program to save energy and water through intuitive green bars.

Removes more than 99,9999% of bacteria and viruses*
The ExtraHygiene function gives you maximum cleaning performance with hygienic care. With the ExtraHygiene function, the final rinse phase heats up to 69°C and keeps the temperature high for minimum 10 minutes to sanitize your dishes, removing more than 99,9999% of bacteria and

*Tested for Micrococcus luteus and MS2 bacteriophage in external test performed by Swissatest Testmaterialien AG in 2021 (Test Report No. 20212029).

• XXL tub
• Auto Off function
• Touch control for programs and functions selection
• Drying system: AirDry Technology
• GlassCare Glass holder lower basket
• Water sensor detects the level of dirt and adjusts water consumption
• Dual safety - Floating switch
• Indications for salt and rinse aid
• FlexiSpray Satellite spray arm
• Ceiling sprayarm
• Height adjustable upper basket, even when fully loaded
• Upper basket with 2 Foldable racks, 2 Foldable wires for glasses, 2 Soft Spikes, 6 wine glass soft grips, Foldable cup shelves, Plastic handle Electrolux
• Lower basket with 2 foldable tines, GlassHolder, Plastic handle
• Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
• Delay Start

Product Specification

Installation	FI	Drying performance index 3 digitE20	1.061
Rated capacity psE20	15	Weighted average energy consumption / 100 cycles, kWh (E20)	76
Energy efficiency class, legal (E20)	C	Water consumption / cycle IE20	11
Airborne acoustical noise emissions, dBA re 1 pW	44	Hinges	Sliding
Door colour	None	Connected load, W	1950
XXL-Tub	Yes	Cord length, m	16
Dimensions_Dishwasher_FSBU_DK	820-900x600x550	Outlet hose length, cm	180
Number of programs	8	Required fuse (A)	10
Number of temperatures	4	Inlet hose length, cm	180
Dimensions HxWxD in mm	818x596x550	Inlet hose type	Aqua control
Airborne acoustical noise emission class	B	Anti-flood device	Floating switch
Depth open door	1230	Water supply	Cold or Hot
Nordic_DW_CutleryType	Cutlery drawer	Upper spray arm	Standard spray arm
Nordic_DW_QuickSelect	Level 3	Lower spray arm	Satellite spray arm
Nordic_DW_SoftGrips	6 SoftGrip holders	Options	ExtraHygiene, GlassCare, XtraPower
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
Nordic_DW_GlassCare2G	Yes	Installation in height	None
Beam on floor	Red&Green	Nordic_DW_DoorPanelHeight	670-825
Interior light	No	Nordic_DW_DoorPanelWeight	15-10
Nordic_DW_DoorFitKit	No	Indicator program	LED Display
Cleaning performance index3 digitE20	1.121	Installation type	Built_In
		Net weight, kg	37.9
		Bar code	7332543975150

PSGBDW120D000002

PSGBDW190DE00003