





SE 3/4 Karusell för bänkhörnskåp 90cm MDF
 DK 3/4 Karrusel for hjørneunderskab 90cm MDF
 NO 3/4 Karusell for hjørneskåp 90cm MDF
 FI 3/4 Karuselli kulmapöytäkaappiin 90cm MDF
 EN 3/4 Carousel for base corner 90cm MDF



Pots & Pans 3/4


E24009034009 E24009034007



9x



1x




1x




5x




18x




3mm




4mm




2x




1x




2x




1x




1x




2x



1x




1x




1x


1




2




3




4




5




6



7




8







18x






2x




2x





2x









UNLOCKED






LOCKED

10





UNLOCKED



LOCKED

11

