








COMPONENTS

Monteringsanvisning Assembly Instructions Asennusohjeet Montageanleitung Monteringsvejledning




# Mesh Basket Roller 18

2448, 2458, 2468, 2488, 2494




1x



i




1




2



3



4





C O M P O N E N T S